



Operating instruction (Translation from the original language) BA.P24.LYY.001.GB_1



gea.com

COPYRIGHT

All rights reserved.

Nothing contained in this documentation may be reproduced or distributed in any form (print, photocopy, microfilm or another method) without the prior written permission of

GEA Hilge

Niederlassung der GEA Tuchenhagen GmbH

hereinafter referred to as **Manufacturer** This restriction also applies to the drawings and diagrams included in the documentation.

LEGAL NOTICE

These instructions are part of the technical documentation, which is part of the scope of delivery. They contain important information to ensure safe and proper transportation, mounting, commissioning, economic operation, maintenance, and repair of the pump. Following these instructions will help you avoid risks, reduce repair costs and downtime and increase the pump's reliability and service life.

These instructions are aimed at users of the pump and are intended in particular for the operator and its operating and maintenance personnel.

It is mandatory for the operator and its operating and maintenance personnel to read these instructions prior to transport, installation, commissioning, use, maintenance, repair, disassembly and disposal of the pump. The obligation to read these instructions applies also to persons responsible for carrying out activities in the phases of the life of the pump.

The operator is required to complement these instructions with information based on existing national regulations for occupational safety, health protection, and environmental protection.

In addition to these instructions and the mandatory regulations for accident prevention applicable in the country and place of use, the recognised technical rules for safe and proper work must be observed.

These instructions are part of the pump. The entire documentation consists of these instructions and any additional instructions provided. It must always be kept within reach at the pump's location of use. When moving the pump to a different site and upon selling the pump, the entire documentation must be passed on as well.

These instructions were written to the best of our conscience. However, the manufacturer is not liable for any errors that may be contained in this document or for any resulting consequences.

The manufacturer reserves the right to make technical changes by further development of the pump described in these instructions.

Illustrations and drawings in these instructions are simplified representations. Due to enhancements and changes, it is possible that the illustrations do not exactly match the pump used by you. The technical data and dimensions are not binding. Claims cannot be derived from them.

The manufacturer assumes no liability for damages

arising within the warranty period due to

- unintended operation and usage conditions,
- insufficient maintenance,
- improper operation,
- incorrect installation,
- incorrect or improper connection of electrical components.
- resulting or arising from unauthorised modifications or failure to follow the instructions,
- caused by use of accessories / spare parts that have not been supplied or recommended by the manufacturer.

LAYOUT INFORMATION

Bullet points and numbered list characters

Bullet points are used to separate logical contents within a section:

Bullet point 1

Types of bullet point 1.

Bullet point 2

Types of bullet point 2.

Numbered list characters are used to separate enumerations within a descriptive text:

Descriptive text with consecutive numbering:

- Numbered list point 1
- Numbered list point 2

Handling instructions

Handling instructions require you to do something. Several consecutive steps result in a handling sequence that should be run in the specified order. The handling sequence can be divided into separate steps.

Handling sequence

- 1. Handling sequence step 1
 - step 1,
 - step 2,
 - step 3.
- 2. Handling sequence step 2

The subsequent handling sequence is the expected result:

 \rightarrow Result of the handling sequence.

Individual handling steps

Individual handling steps are marked thus:

- Individual work steps

TABLE OF CONTENTS

| 1 | General | 9 |
|-------|--|----------|
| 1.1 | Information about this document | 9 |
| 1.2 | Manufacturer address | 9 |
| 1.3 | Customer service | |
| 1.4 | EU Declaration of Conformity for Machines | |
| 1.5 | UKCA - Declaration of Conformity | |
| 2 | Safety | 12 |
| 2.1 | Intended use | |
| 2.1.1 | Pumped fluids | |
| 2.1.2 | Minimum flow rate | 12 |
| | Minimum flow rates in explosive atmospheres | 12 |
| 2.1.3 | Connections and piping | |
| 2.1.4 | Switching frequency | |
| 2.1.5 | Types | 12 |
| 2.1.6 | Hygiene classification | 13 |
| 2.2 | Safety precautions in these operating instructions | 13 |
| 2.3 | Explanation of the safety symbols used | 14 |
| 2.4 | Safety instructions for the company/operator | 14 |
| 2.4.1 | Dangers of non-compliance with safety information | 15 |
| 2.4.2 | Safety-conscious work behaviour | |
| 2.5 | Unauthorised modification and ordering of spare parts | |
| 2.6 | Staff qualifications and training | |
| 2.7 | Safety equipment | |
| 2.8 | Possible residual hazards | |
| 3 | Description | |
| 3.1 | Pump overview | |
| 3.2 | Description | |
| 3.2.1 | Standard version applications | |
| 3.2.2 | Hygienic design applications | |
| 3.3 | Pump name | |
| 3.4 | Typenschild | |
| 4 | Transport and Storage | |
| 4.1 | Special personnel qualification for transport and storage | 20 |
| 4.2 | Safety precautions for transport and storage | |
| 4.3 | Dimensions / weights | 21 |
| 4.4 | Unpacking the pump | 21 |
| 4.5 | Disposal of packaging material | |
| 5 | Technical data | |
| 5.1 | Serial number | |
| 5.2 | Performance data | 22 |
| 5.3 | Noise emissions | |
| 5.4 | Maximum operating temperatures | |
| 5.5 | Maximum operating pressure | |
| 6 | Assembly and installation | |
| 6.1 | Safety precautions for setup, installation, and connection | |
| 6.2 | Special personnel qualification | |
| 6.3 | Setup, installation, and connection | |
| 6.3.1 | Checking smooth running of the impeller | |
| 6.3.2 | Setting up and aligning the pump unit | |
| 6.3.3 | Installation in the piping system | |
| | Space requirements Noise and vibration damping | 27 28 |
| 6.3.4 | Using the mechanical seal | |
| 6.3.5 | Flush connections for double mechanical seals (optional) | |
| 0.0.0 | Flushing fluid (optional) | |
| | Double mechanical seals (optional) | |
| 6.3.6 | Electrical connection | |
| 5.5.0 | Star connection | |
| | Delta connection | |
| | Frequency converter operation | |
| | | |

| 7 Commissioning 38 7.1 Special personnel qualification 38 7.3 Commissioning / Initial startup 38 7.3.1 Checking conditions of use 36 7.3.2 Commissioning of the pump 36 7.3.3 Functional testing of the mechanical seal 37 8 Cleaning 38 8.1 Special personnel qualification 38 8.3 CIP 38 8.4 SiP 36 9 Maintenance / servicing 44 9.1 Safety instructions for maintenance and repair 44 9.2 Safety instructions for maintenance and repair 44 9.3 Pump maintenance 41 9.4 Maintenance of the L-bearing 44 9.2 Maintenance of the L-bearing 42 9.4.1 Studuer of the L-bearing 42 9.4.1 Studuer of the L-bearing 42 9.4.1 Studuer of the L-bearing 42 9.4.2 Bearing replacement 42 </th <th></th> <th>Checking the direction of rotation after connecting</th> <th></th> | | Checking the direction of rotation after connecting | |
|--|---------|---|----|
| 7.1 Special personnel qualification 33 7.2 Safety instructions for commissioning 38 7.3.1 Checking conditions of use 38 7.3.2 Commissioning of the pump 38 7.3.3 Functional testing of the mechanical seal 37 7.3.3 Functional testing of the mechanical seal 37 8 Cleaning 38 2.5 Safety instructions 38 3.2 Safety instructions 38 3.3 CIP 38 4.4 Special personnel qualification 38 3.5 Safety instructions for maintenance and repair 41 9.1 Safety instructions for maintenance 41 9.3 Pum maintenance 41 9.3.1 Inspections 41 8.4 Syle the L-bearing 42 9.4 Maintenance of the L-bearing 42 9.4 Structure of the L-bearing 42 9.4.4 Grease filling 43 9.5 Maintenance of the utoba 44 9.5 Maintenance of the notor 44 | | | 34 |
| 7.2 Safety instructions for commissioning | 7 | | |
| 7.3 Commissioning / initial startup | | | |
| 7.3.1 Checking conditions of use 38 7.3.2 Commissioning of the pump 38 7.3.3 Functional testing of the mechanical seal 37 8 Cleaning 38 8.1 Special personnel qualification 38 8.2. Safety instructions 38 8.4. SIP | | | |
| 7.3.2 Commissioning of the pump 32 7.3.3 Functional testing of the mechanical seal 337 8 Cleaning 38 8.1 Special personnel qualification 38 8.2 Safety instructions 38 8.3 CIP 39 8.4 SIP 44 9 Maintenance / servicing 44 9 Maintenance / servicing 44 9.1 Safety instructions for maintenance and repair 41 9.2 Special personnel qualification 41 9.3 Pump maintenance 44 Replacement of O-rings 44 9.4 Maintenance of the L-bearing 42 9.4.1 Structure of the L-bearing 42 9.4.2 Bearing replacement 43 9.4.3 Premature bearing replacement 43 9.4.4 Grease filing 43 9.5 Maintenance of the motor 44 10.4 Repair order 44 10.4 Repair order 44 10.4 Repair order 44 | | | |
| 7.3.3 Functional testing of the mechanical seal 37 8 Cleaning 38 8.1 Special personnel qualification 38 8.2 Safety instructions 38 8.3 CIP 38 8.4 SIP 36 8.5 Manual exterior cleaning 44 9 Maintenance / servicing 41 9.1 Safety instructions for maintenance and repair 41 9.2 Special personnel qualification 41 9.3.1 Inspections 41 9.3.2 Maintenance of the L-bearing 42 9.4 Maintenance of the L-bearing 42 9.4 Maintenance of the L-bearing 42 9.4.3 Premature bearing replacement 43 9.4 Maintenance of the motor 42 9.5 Maintenance of the motor 42 9. | | | |
| 8 Cleaning 38 8.1 Special personnel qualification 38 8.2 Safety instructions 38 8.3 CIP 39 8.4 SIP 40 9 Maintenance / servicing 41 9.1 Safety instructions for maintenance and repair 41 9.2 Special personnel qualification 41 9.3 Pump maintenance 41 9.3 Pump maintenance 41 9.3 Pump maintenance 41 9.4 Maintenance intervals 44 9.4 Maintenance of the L-bearing 42 9.4.1 Structure of the L-bearing 42 9.4.2 Bearing replacement 43 9.4.3 Premature bearing replacement 43 9.4.4 Grease filing 43 7.5 Maintenance of the motor 44 40.1 Special personnel qualification 46 10.4 Repair order 44 10.4 Repair order 45 10.4 Repair 46 | | | |
| 8.1 Special personnel qualification 38 8.2 Safety instructions 38 8.3 CIP 38 8.4 SIP 38 8.5 Manual exterior cleaning 40 9 Maintenance / servicing 41 9.1 Safety instructions for maintenance and repair 41 9.1 Special personnel qualification 41 9.3 Pump maintenance 41 9.3.1 Inspections 41 7.8 Special personnel qualification 41 9.3.1 Inspections 41 7.8 Maintenance of the L-bearing 42 9.4 Maintenance of the L-bearing 42 9.4.1 Structure of the L-bearing 42 9.4.2 Bearing replacement 43 9.4.3 Premature bearing replacement 43 9.4.4 Grease filling 44 10 Malfunctions / repairs 46 10.1 Special personnel qualification 46 10.2 Safety instructions 47 10.4 Repair< | | - | |
| 8.2 Safety instructions 38 8.3 CIP 38 8.4 SIP 44 8.5 Manual exterior cleaning 44 8.6 SIP 44 9 Maintenance / servicing 41 9.1 Safety instructions for maintenance and repair 41 9.2 Special personnel qualification 41 9.3.1 Inspections 41 Replacement of O-rings 41 9.3.2 Maintenance intervals 42 9.4 Maintenance of the L-bearing 42 9.4.1 Structure of the L-bearing 42 9.4.2 Bearing replacement 43 9.4.3 Premature bearing grepases 43 9.5 Maintenance of the motor 46 10.1 Special personnel qualification 46 10.2 Safety instructions 46 10.3 Malfunctions and remedies 47 10.4 Repair 46 10.4 Repair 46 10.4.1 Repair order 47 10.4.2 | | | |
| 8.3 CIP | - | | |
| 8.4 SIP 40 8.5 Manual exterior cleaning 41 9 Maintenance / servicing 41 9.1 Safety instructions for maintenance and repair 41 9.2 Special personnel qualification 41 9.3.1 Inspections 41 9.3.2 Maintenance intervals 42 9.4 Maintenance of the L-bearing 42 9.4.1 Structure of the L-bearing 42 9.4.2 Bearing replacement 43 9.4.4 Grease filing 42 Roller bearing greases 43 9.5 Maintenance of the motor 44 10 Malfunctions / repairs 46 10.1 Special personnel qualification 46 10.2 Safety instructons 46 10.3 Malfunctions and remedies 47 10.4 Repair order 48 10.4 Repair order 46 10.4.1 Repair order 46 10.4.2 Grease filing outsing 55 10.4 Repair order 46 | | | |
| 8.5 Manual exterior cleaning 40 9 Maintenance / servicing 41 9.1 Safety instructions for maintenance and repair 41 9.2 Special personnel qualification 41 9.3 Pump maintenance 41 9.3.1 Inspections 41 Replacement of O-rings 41 9.4.4 Maintenance of the L-bearing 42 9.4.1 Structure of the L-bearing 42 9.4.3 Premature bearing replacement 43 9.4.3 Premature bearing replacement 43 9.4.4 Grease filling 43 7.6 Maintenance of the motor 46 10 Malfunctions / repairs 46 10.1 Special personnel qualification 46 10.2 Safety instructions 47 10.4.4 Repair 46 10.4.2 GEA Hilge assembly tool kit 46 10.4.3 Parts overview 55 10.4.4 Repair order 55 10.4.4 Repair order 55 10.4.2 GEA Hilg | | | 39 |
| 9 Maintenance / servicing 41 9.1 Safety instructions for maintenance and repair 41 9.2 Special personnel qualification 41 9.3 Pump maintenance 41 9.3.1 Inspections 41 Replacement of O-rings 41 9.3.2 Maintenance intervals 42 9.4 Maintenance of the L-bearing 42 9.4.2 Bearing replacement 43 9.4.3 Premature bearing replacement 43 9.4.4 Grease filling 43 Roller bearing greases 43 9.5 Maintenance of the motor 45 10 Malfunctions / repairs 46 10.2 Safety instructions 46 10.3 Malfunctions and remedies 47 10.4 Repair 42 10.4 Repair 42 </td <td>-</td> <td></td> <td></td> | - | | |
| 9.1 Safety instructions for maintenance and repair 44 9.2 Special personnel qualification 44 9.3 Pump maintenance 41 9.3 Pump maintenance 41 9.3 Pump maintenance 41 Replacement of O-rings 41 9.4 Maintenance intervals 42 9.4 Maintenance of the L-bearing 42 9.4.1 Structure of the L-bearing 42 9.4.2 Bearing replacement 43 9.4.3 Premature bearing replacement 43 9.4.4 Grease filling 43 Roller bearing greases 43 0.5 Maintenance of the motor 46 10.1 Special personnel qualification 46 10.2 Safety instructions 46 10.4 Repair 44 10.4 Repair 44 10.4 Repair 47 10.4.2 GEA Hilge assembly tool kit 46 10.4.4 Gease filling model 47 10.4.7 Parts overview 55 | | Manual exterior cleaning | 40 |
| 9.2 Special personnel qualification 41 9.3 Pump maintenance 41 9.3.1 Inspections 41 Replacement of O-rings 41 9.3.2 Maintenance of the L-bearing 42 9.4 Maintenance of the L-bearing 42 9.4.1 Structure of the L-bearing 42 9.4.2 Bearing replacement 43 9.4.3 Premature bearing replacement 43 9.4.4 Grease filling 43 9.4.5 Maintenance of the motor 44 0.4.6 Maintenance of the motor 44 0.7 Special personnel qualification 46 10.1 Special personnel qualification 46 10.2 Safety instructions 44 10.4 Repair 44 10.4.1 Repair 44 10.4.2 GEA Hilg assembly tool kit 45 10.4.3 Parts overview U-bearing housing 55 10.4.4 Parts overview U-bearing housing 55 10.4.5 Parts overview U-bearing housing 55 1 | | Maintenance / servicing | 41 |
| 9.3 Pump maintenance 41 9.3.1 Inspections 41 Replacement of O-rings 41 9.4.1 Structure of the L-bearing 42 9.4.4 Maintenance intervals 42 9.4.2 Bearing replacement 42 9.4.3 Premature bearing replacement 43 9.4.4 Grease filling 43 Roller bearing greases 43 9.5 Maintenance of the motor 44 10 Malfunctions / repairs 46 10.2 Safety instructions 46 10.3 Malfunctions and remedies 47 10.4 Repair 46 10.4 Repair 46 10.4.1 Repair order 46 10.4.2 GEA Hilge assembly tool kit 46 10.4.2 GEA Hilge assembly tool kit 46 10.4.3 Parts overview 50 10.4.4 Repair order 52 10.4.5 Parts overview of motor connection and motor 52 10.4.6 Disassemble the pump 53 | | | |
| 9.3.1 Inspections 44 Replacement of O-ings 44 9.3.2 Maintenance intervals 42 9.4.4 Maintenance of the L-bearing 42 9.4.1 Structure of the L-bearing 42 9.4.2 Bearing replacement 43 9.4.3 Premature bearing replacement 43 9.4.4 Grease filling 43 9.5 Maintenance of the motor 44 10 Malfunctions / repairs 46 10.1 Special personnel qualification 46 10.2 Safety instructions 46 10.4 Repair 48 10.4.1 Repair 48 10.4.2 Safety instructions 46 10.4.3 Parts overview 47 10.4.4 Repair 48 10.4.1 Repair 48 10.4.2 Safety instructions 45 10.4.3 Parts overview U-bearing housing 55 10.4.4 Repair 48 10.4.5 Parts overview of motor connection and motor 55 | | | |
| Replacement of O-rings 44 9.3.2 Maintenance intervals 42 9.4 Maintenance of the L-bearing 42 9.4.1 Structure of the L-bearing 42 9.4.2 Bearing replacement 43 9.4.3 Premature bearing replacement 43 9.4.4 Grease filling 43 9.4.4 Grease filling 43 9.5 Maintenance of the motor 45 10 Malfunctions / repairs 46 10.1 Special personnel qualification 46 10.2 Safety instructions and remedies 47 10.4 Repair 46 10.4.1 Repair order 48 10.4.2 GEA Hige assembly tool kit 49 10.4.3 Parts overview L-bearing housing 51 10.4.4 Parts overview of motor connection and motor 52 10.4.4 Parts overview of motor connection and motor 52 10.4.5 Parts overview for motor connection and motor 52 10.4.6 Disassemble the pump 53 10.4.7 Installiton instructions </td <td></td> <td></td> <td></td> | | | |
| 9.3.2 Maintenance intervals 42 9.4 Maintenance of the L-bearing 42 9.4.1 Structure of the L-bearing 43 9.4.2 Bearing replacement 43 9.4.3 Premature bearing replacement 43 9.4.4 Grease filling 43 9.5 Maintenance of the motor 44 10 Malfunctions / repairs 46 10.1 Special personnel qualification 46 10.2 Safety instructions 46 10.3 Malfunctions and remedies 47 10.4.1 Repair 48 10.4.2 GEA Hilge assembly tool kit 46 10.4.3 Parts overview 46 10.4.4 Repair 45 10.4.5 Parts overview of motor connection and motor 55 10.4.6 Disassemble the pump 55 10.4.6 Disassemble the pump 55 10.4.6 Disassemble the pump 55 10.4.7 Installation instructions 55 10.4.8 Parts overview of motor connection and motor 55 </td <td>9.3.1</td> <td>•</td> <td></td> | 9.3.1 | • | |
| 9.4 Maintenance of the L-bearing 42 9.4.1 Structure of the L-bearing 42 9.4.2 Bearing replacement 43 9.4.3 Premature bearing replacement 43 9.4.4 Grease filling 43 Roller bearing greases 43 9.5 Maintenance of the motor 46 10 Malfunctions / repairs 46 10.1 Special personnel qualification 46 10.2 Safety instructions 47 10.3 Maifunctions and remedies 47 10.4 Repair 47 10.4.1 Repair 48 10.4.2 GEA Hilge assembly tol kit 49 10.4.3 Parts overview L-bearing housing 50 10.4.4 Parts overview of motor connection and motor 52 10.4.5 Parts overview of motor connection and motor 52 10.4.6 Disassemble the pump 53 10.4.7 Installion instructions | 0 2 2 | | |
| 9.4.1 Structure of the L-bearing 42 9.4.2 Bearing replacement 43 9.4.3 Premature bearing replacement 43 9.4.4 Grease filling 43 Roller bearing greases 43 9.5 Maintenance of the motor 44 10 Malfunctions / repairs 46 10.1 Special personnel qualification 46 10.2 Safety instructions 46 10.3 Malfunctions and remedies 47 10.4 Repair 46 10.4.1 Repair order 46 10.4.2 GEA Hilge assembly tool kit 47 10.4.3 Parts overview 46 10.4.4 Repair order 46 10.4.2 GEA Hilge assembly tool kit 47 10.4.4 Parts overview L-bearing housing 55 10.4.5 Parts overview U-bearing housing 55 10.4.6 Disassemble the pump 52 10.4.6 Disassemble the pump 53 10.4.7 Parts overview of motor connection and motor 55 10.4 | | | |
| 9.4.2 Bearing replacement 43 9.4.3 Premature bearing replacement 43 9.4.4 Grease filing 43 Roller bearing greases 43 9.5 Maintenance of the motor 44 10 Malfunctions / repairs 46 10.1 Special personnel qualification 46 10.2 Safety instructions 46 10.3 Malfunctions and remedies 47 10.4 Repair 48 10.4.1 Repair order 48 10.4.2 GEA Hilge assembly tool kit 48 10.4.3 Parts overview 48 10.4.4 Parts overview 48 10.4.3 Parts overview 48 10.4.4 Parts overview of motor connection and motor 52 10.4.5 Parts overview of motor connection and motor 52 10.4.4 Parts overview of motor connection and motor 52 10.4.4 Parts overview of motor connection and motor 52 10.4.6 Disassemble the pump 53 10.4.7 Installiton instructions 53 <td></td> <td>Structure of the L bearing</td> <td>42</td> | | Structure of the L bearing | 42 |
| 9.4.3 Premature bearing replacement 43 9.4.4 Grease filling 43 Roller bearing greases 43 9.5 Maintenance of the motor 45 10 Malfunctions / repairs 46 10.1 Special personnel qualification 46 10.2 Safety instructions 46 10.3 Malfunctions and remedies 47 10.4 Repair 46 10.4.1 Repair order 48 10.4.2 GEA Hilge assembly tool kit 48 10.4.2 GEA Hilge assembly tool kit 49 10.4.2 GEA Hilge assembly tool kit 49 10.4.3 Parts overview I-bearing housing 56 10.4.4 Parts overview I-bearing housing 51 10.4.5 Parts overview I-bearing housing 52 10.4.6 Disassemble the pump 52 10.4.7 Parts overview I-bearing housing 53 10.4.8 Cleaning the components before assembly 53 10.4.9 Mounting I-bearing housing 53 10.4.10 Installing the single-fluxed mech | •••• | | 42 |
| 9.4.4 Grease filling 43 Roller bearing greases 43 Roller bearing greases 43 10 Malfunctions / repairs 46 10.1 Special personnel qualification 46 10.2 Safety instructions 46 10.3 Malfunctions and remedies 47 10.4 Repair 48 10.4.1 Repair order 48 10.4.2 GEA Hilge assembly tool kit 49 Contents and use 49 Contents and use 49 10.4.3 Parts overview _ 50 10.4.4 Parts overview of motor connection and motor 52 10.4.5 Parts overview of motor connection and motor 52 10.4.6 Disassemble the pump 53 10.4.7 Installation instructions 53 10.4.8 Cleaning the components before assembly 53 10.4.9 Mounting L-bearing housing 53 10.4.10 Mounting the single-flushed mechanical seal 56 10.4.11 Installing the single-flushed mechanical seal 56 10.4. | | | |
| Roller bearing greases 43 9.5 Maintenance of the motor 45 10 Malfunctions / repairs 46 10.1 Special personnel qualification 46 10.2 Safety instructions 46 10.3 Malfunctions and remedies 47 10.4 Repair 48 10.4.1 Repair order 48 10.4.2 GEA Hilge assembly tool kit 49 Contents and use 49 10.4.3 Parts overview 50 10.4.4 Parts overview Lobearing housing 51 10.4.5 Parts overview of motor connection and motor 52 10.4.6 Disassemble the pump 53 10.4.7 Installation instructions 53 10.4.8 Cleaning the components before assembly 53 10.4.9 Mounting housing cover 53 10.4.1 Installing insigne mechanical seal 56 10.4.10 Mounting housing cover 55 10.4.11 Installing single mechanical seal 56 10.4.12 Installing the single-flushed mechanical seal <td< td=""><td></td><td></td><td></td></td<> | | | |
| 9.5 Maintenance of the motor 44 10 Malfunctions / repairs 46 10.1 Special personnel qualification 46 10.2 Safety instructions 46 10.3 Malfunctions and remedies 47 10.4 Repair 46 10.4.1 Repair order 48 10.4.2 GEA Hilge assembly tool kit 49 Contents and use 49 10.4.3 Parts overview L-bearing housing 51 10.4.4 Parts overview L-bearing housing 52 10.4.5 Parts overview L-bearing housing 52 10.4.6 Disassemble the pump 52 10.4.6 Disassemble the pump 53 10.4.7 Installation instructions 53 10.4.8 Cleaning the components before assembly 53 10.4.9 Mounting L-bearing housing 53 10.4.10 Mounting the gap size 56 10.4.11 Determining the gap size 56 10.4.12 Installing the double mechanical seal 56 10.4.13 Installing the ouble mechanical seal | 5.7.7 | | |
| 10 Malfunctions / repairs 46 10.1 Special personnel qualification 46 10.2 Safety instructions 46 10.3 Malfunctions and remedies 47 10.4 Repair 48 10.4.1 Repair order 48 10.4.2 GEA Hilge assembly tool kit 49 Contents and use 49 10.4.3 Parts overview 49 10.4.4 Parts overview 50 10.4.5 Parts overview L-bearing housing 51 10.4.5 Parts overview of motor connection and motor 52 10.4.6 Disassemble the pump 52 10.4.7 Installation instructions 53 10.4.8 Cleaning the components before assembly 53 10.4.8 Cleaning the components before assembly 53 10.4.9 Mounting L-bearing housing 53 10.4.10 Mounting the gap size 56 10.4.11 Determining the gap size 56 10.4.12 Installing the single-flushed mechanical seal 66 10.4.14 Installing the impelle | 95 | Maintenance of the motor | 43 |
| 10.1 Special personnel qualification 44 10.2 Safety instructions 46 10.3 Malfunctions and remedies 47 10.4 Repair 48 10.4.1 Repair order 48 10.4.2 GEA Hilge assembly tool kit 48 10.4.3 Parts overview 49 10.4.4 Parts overview 50 10.4.4 Parts overview of motor connection and motor 52 10.4.5 Parts overview of motor connection and motor 52 10.4.6 Disassemble the pump 53 10.4.7 Installation instructions 53 10.4.8 Cleaning the components before assembly 53 10.4.9 Mounting L-bearing housing 53 10.4.10 Mounting the gap size 56 10.4.11 Determining the gap size 56 10.4.12 Installing single mechanical seal 56 10.4.13 Installing the double mechanical seal 66 10.4.14 Installing the double mechanical seal 66 10.4.15 Installing the impeller and housing 66 | | Malfunctions / renairs | |
| 10.2 Safety instructions 44 10.3 Malfunctions and remedies 47 10.4 Repair 48 10.4.1 Repair order 48 10.4.2 GEA Hilge assembly tool kit 49 Contents and use 49 10.4.3 Parts overview 49 Contents and use 49 10.4.3 Parts overview L-bearing housing 50 10.4.4 Parts overview of motor connection and motor 52 10.4.5 Parts overview of motor connection and motor 52 10.4.6 Disassemble the pump 52 10.4.7 Installation instructions 53 10.4.8 Cleaning the components before assembly 53 10.4.9 Mounting the bay is 2 53 10.4.10 Mounting the ousing 53 10.4.9 Mounting the gap size 56 10.4.11 Determining the gap size 56 10.4.12 Installing the double mechanical seal 66 10.4.14 Installing the ouble mechanical seal 66 10.4.14 Installing the ouble mechanical seal tand | - | Special personnel qualification | |
| 10.3 Malfunctions and remedies 47 10.4 Repair 48 10.4.1 Repair order 48 10.4.2 GEA Hilge assembly tool kit 49 10.4.3 Parts overview 49 10.4.4 Parts overview 49 10.4.5 Parts overview of motor connection and motor 50 10.4.4 Parts overview of motor connection and motor 52 10.4.5 Parts overview of motor connection and motor 52 10.4.6 Disassemble the pump 52 10.4.7 Installation instructions 53 10.4.8 Cleaning the components before assembly 53 10.4.9 Mounting L-bearing housing 53 10.4.10 Mounting Lobaring housing cover 55 10.4.10 Mounting housing cover 56 10.4.11 Determining the gap size 56 10.4.12 Installing the single-flushed mechanical seal 60 10.4.14 Installing the impeller and housing 62 10.4.15 Installing the impeller and housing 62 11.1 Special personnel qualification | | | |
| 10.4 Repair 48 10.4.1 Repair order 48 10.4.1 Repair order 48 10.4.2 GEA Hilge assembly tool kit 49 Contents and use 49 10.4.3 Parts overview 49 10.4.4 Parts overview lobearing housing 50 10.4.5 Parts overview of motor connection and motor 52 10.4.6 Disassemble the pump 52 10.4.7 Installation instructions 53 10.4.8 Cleaning the components before assembly 53 10.4.9 Mounting Lobearing housing 53 10.4.9 Mounting Lobearing housing 53 10.4.10 Mounting housing cover 55 10.4.10 Mounting housing cover 56 10.4.10 Mounting housing cover 56 10.4.11 Determining the gap size 56 10.4.11 Determining the gap size 56 10.4.12 Installing the single-flushed mechanical seal 66 10.4.13 Installing the impeller and housing 62 10.4.15 Installing the i | | | |
| 10.4.1 Repair order | | | |
| 10.4.2 GEA Hilge assembly tool kit | | | |
| Contents and use 49 10.4.3 Parts overview 50 10.4.4 Parts overview L-bearing housing 51 10.4.5 Parts overview of motor connection and motor 52 10.4.6 Disassemble the pump 52 10.4.7 Installation instructions 53 10.4.8 Cleaning the components before assembly 53 10.4.9 Mounting L-bearing housing 53 10.4.10 Mounting housing cover 55 10.4.11 Determining the gap size 56 10.4.12 Installing single mechanical seal 56 10.4.12 Installing the single-flushed mechanical seal 60 10.4.14 Installing the double mechanical seal tandem 62 10.4.15 Installing the impeller and housing 65 11.1 Special personnel qualification 69 11.1 Special personnel qualification 69 11.3 Temporary decommissioning 69 11.4 Disposal 69 11.4 Disposal 69 | | | |
| 10.4.3 Parts overview 500 10.4.4 Parts overview L-bearing housing 511 10.4.5 Parts overview of motor connection and motor 522 10.4.6 Disassemble the pump 522 10.4.7 Installation instructions 533 10.4.8 Cleaning the components before assembly 533 10.4.9 Mounting L-bearing housing 533 10.4.10 Mounting housing cover 553 10.4.11 Determining the gap size 566 10.4.12 Installing single mechanical seal 566 10.4.13 Installing the single-flushed mechanical seal 662 10.4.14 Installing the single-flushed mechanical seal 662 10.4.15 Installing the impeller and housing 653 11.1 Decommissioning 659 11.1 Special personnel qualification 699 11.2 Safety instructions 699 11.3 Temporary decommissioning 699 11.4 Disposal 699 11.4 Disposal 699 11.4 Disposal 690 | 10.1.2 | | |
| 10.4.5 Parts overview of motor connection and motor 52 10.4.6 Disassemble the pump 52 10.4.7 Installation instructions 53 10.4.8 Cleaning the components before assembly 53 10.4.9 Mounting L-bearing housing 53 10.4.10 Mounting housing cover 55 10.4.11 Determining the gap size 56 10.4.12 Installing single mechanical seal 56 10.4.13 Installing the single-flushed mechanical seal 56 10.4.14 Installing the double mechanical seal 60 10.4.15 Installing the impeller and housing 62 11.1 Special personnel qualification 69 11.2 Safety instructions 69 11.3 Temporary decommissioning 69 11.4 Disposal 69 | 10.4.3 | | 50 |
| 10.4.5 Parts overview of motor connection and motor 52 10.4.6 Disassemble the pump 52 10.4.7 Installation instructions 53 10.4.8 Cleaning the components before assembly 53 10.4.9 Mounting L-bearing housing 53 10.4.10 Mounting housing cover 55 10.4.11 Determining the gap size 56 10.4.12 Installing single mechanical seal 56 10.4.13 Installing the single-flushed mechanical seal 56 10.4.14 Installing the double mechanical seal 60 10.4.15 Installing the impeller and housing 62 11.1 Special personnel qualification 69 11.2 Safety instructions 69 11.3 Temporary decommissioning 69 11.4 Disposal 69 | 10.4.4 | Parts overview L-bearing housing | 51 |
| 10.4.6 Disassemble the pump | 10.4.5 | | |
| 10.4.7 Installation instructions 53 10.4.8 Cleaning the components before assembly 53 10.4.9 Mounting L-bearing housing 53 10.4.9 Mounting L-bearing housing 53 10.4.10 Mounting housing cover 55 10.4.11 Determining the gap size 56 10.4.12 Installing single mechanical seal 56 10.4.13 Installing the single-flushed mechanical seal 56 10.4.13 Installing the double mechanical seal 60 10.4.14 Installing the double mechanical seal tandem 62 10.4.15 Installing the impeller and housing 65 11 Decommissioning 69 11.1 Special personnel qualification 69 11.2 Safety instructions 69 11.3 Temporary decommissioning 69 11.4 Disposal 69 11.4 Disposal 69 11.4 Disposal 69 11.4 Appendix 70 | 10.4.6 | | |
| 10.4.9 Mounting L-bearing housing | 10.4.7 | | |
| 10.4.10 Mounting housing cover 55 10.4.11 Determining the gap size 56 10.4.12 Installing single mechanical seal 58 10.4.13 Installing the single-flushed mechanical seal 60 10.4.14 Installing the double mechanical seal tandem 62 10.4.15 Installing the impeller and housing 65 11 Decommissioning 65 11.1 Special personnel qualification 69 11.2 Safety instructions 69 11.3 Temporary decommissioning 69 11.4 Disposal 69 11.4 Disposal 69 11.4 Disposal 69 12 Appendix 70 | 10.4.8 | Cleaning the components before assembly | 53 |
| 10.4.11 Determining the gap size | 10.4.9 | Mounting L-bearing housing | 53 |
| 10.4.12 Installing single mechanical seal | 10.4.10 | Mounting housing cover | 55 |
| 10.4.13 Installing the single-flushed mechanical seal60 10.4.14 Installing the double mechanical seal tandem62 10.4.15 Installing the impeller and housing65 11 Decommissioning69 11.1 Special personnel qualification69 11.2 Safety instructions69 11.3 Temporary decommissioning69 11.4 Disposal69 12 Appendix70 | 10.4.11 | | |
| 10.4.14 Installing the double mechanical seal tandem62 10.4.15 Installing the impeller and housing65 11 Decommissioning69 11.1 Special personnel qualification69 11.2 Safety instructions69 11.3 Temporary decommissioning69 11.4 Disposal69 12 Appendix70 | 10.4.12 | | |
| 10.4.15 Installing the impeller and housing | | | |
| 11 Decommissioning 69 11.1 Special personnel qualification 69 11.2 Safety instructions 69 11.3 Temporary decommissioning 69 11.4 Disposal 69 12 Appendix 70 | | • | |
| 11.1 Special personnel qualification69 11.2 Safety instructions69 11.3 Temporary decommissioning69 11.4 Disposal69 12 Appendix70 | | | |
| 11.1 Special personnel qualification69 11.2 Safety instructions69 11.3 Temporary decommissioning69 11.4 Disposal69 12 Appendix70 | 11 | Decommissioning | 69 |
| 11.3 Temporary decommissioning69 11.4 Disposal69 12 Appendix70 | 11.1 | Special personnel qualification | 69 |
| 11.4 Disposal 69 12 Appendix 70 | 11.2 | | |
| 12 Appendix70 | 11.3 | | |
| | | • | |
| 12.1 Certificate of non-objection 71 | 12 | Appendix | 70 |
| | 12.1 | Certificate of non-objection | 71 |

TABLE OF FIGURES

| Fig. 1 | | 18 |
|---------|--|----|
| Fig. 2 | Anchor points (example) | 20 |
| Fig. 3 | Permissible setups of the pump | 27 |
| Fig. 4 | Installation in the piping system | 27 |
| Fig. 5 | Minimum distances in horizontal installation | 28 |
| Fig. 6 | Example of a foundation of a pump | 28 |
| Fig. 7 | Lubrication film between the sliding surfaces | 30 |
| Fig. 8 | Flush ports | 31 |
| Fig. 9 | Star connection | 33 |
| Fig. 10 | Delta connection | 33 |
| Fig. 11 | Earthing connection of the motor shroud | 35 |
| Fig. 12 | Earthing the machine pad support | 35 |
| Fig. 13 | Lubrication information plate of MGE motor (example) | 45 |
| Fig. 14 | GEA Hilge assembly tool kit | 49 |
| Fig. 15 | HYGIA H III | |
| Fig. 16 | L-bearing housing | |
| Fig. 17 | Motor connection and motor | |
| Fig. 18 | Back plate with stud bolts | 55 |
| Fig. 19 | Contact surface of back plate / structural part | 55 |
| Fig. 20 | Back plate on the structural part | |
| Fig. 21 | Gap size HYGIA H | 56 |
| Fig. 22 | Single mechanical seal | 58 |
| Fig. 23 | Rotary ring, synthetic material assembly aid | 59 |
| Fig. 24 | Stationary ring, synthetic material assembly aid | 59 |
| Fig. 25 | Single flushed mechanical seal | 60 |
| Fig. 26 | Double mechanical seal tandem | |
| Fig. 27 | Impeller nut | 65 |
| Fig. 28 | Lock washers | 65 |
| Fig. 29 | Grease overview | 65 |
| Fig. 30 | Lock washer | |
| Fig. 31 | Lock washers in impeller nut | 66 |
| Fig. 32 | Impeller nut | 66 |
| Fig. 33 | O-ring | 66 |
| Fig. 34 | | 67 |
| Fig. 35 | Impeller nut | |
| Fig. 36 | Eye bolt for lifting device | 67 |
| Fig. 37 | Stud bolts in the HP housing | 67 |

1 General

1.1 Information about this document

Target group

These operating instructions are intended for:

- the operator/user of the pump,
- the maintenance and service personnel.

The instructions assume a general common technical understanding, which is necessary for the commissioning, maintenance and servicing of pump units. Sections that are aimed only at special authorised personnel are indicated by a preceding note.

Text highlights

The following symbols and text formatting facilitate the reading of this document:

- Bullets and lists points
- Instructions.

Instructions that must be executed in a certain order are numbered according to the sequence.

For the marking of safety instructions, please refer to Section 2.3, Page 14.

Technical changes

Types, technical data and spare part numbers are subject to technical change. We reserve the right to implement changes due to technical progress.

1.2 Manufacturer address

GEA Hilge Niederlassung der GEA Tuchenhagen GmbH Hilgestraße 37-47 55294 Bodenheim Germany Phone +49 6135 7016-0 Fax +49 6135 1737 hilge@gea.com gea.com

1.3 Customer service

Phone +49 6135 7016 100 (Sales support) Phone +49 6135 7016101 (Service) spareparts.hilge@gea.com

1.4 EU Declaration of Conformity for Machines in accordance with the EC Machinery Directive 2006/42/EC, Annex II 1. A

We, as the manufacturer, declare under our sole responsibility that the machine

| Designation: | Designation: |
|---------------|--|
| Model / Type: | GEA Hilge HYGIA H I ADAPTA, ADAPTA-SUPER |
| | GEA Hilge HYGIA H II ADAPTA, ADAPTA-SUPER |
| | GEA Hilge HYGIA H III L, L- SUPER |

conforms with all the relevant provisions of this directive and the following directives:

| Relevant EC directives: | 2006/42/EC | EC Machinery Directive |
|---|--|---|
| Applicable harmonized standards, in particular: | EN 809:1998/A1+AC(D) | |
| | EN ISO 12100:2010 | |
| Remarks: | We also declare that the releva this machine has been prepare Part A, and agree to submit the request of national authorities o | d in accordance with Annex VII, documentation on justified |
| | | |

Person authorised for compilation and handover of technical documentation:

GEA HILGE Niederlassung der GEA Tuchenhagen GmbH Hilgestraße 37-47 55294 Bodenheim, Deutschland

Bodenheim, den 02.11.2022

Karsten Becker Managing Director

i.V. D. Aug

i. V. Dr. Danijel Anciger Manager Product Development

1.5 UKCA - Declaration of Conformity

We herewith declare,

GEA HILGE Niederlassung der GEA Tuchenhagen GmbH Hilgestraße 37-47 D 55294 Bodenheim

| Denomination: | Centrifugal pump |
|---------------|---|
| Model / Type: | GEA Hilge HYGIA H I ADAPTA, ADAPTA-SUPER |
| | GEA Hilge HYGIA H II ADAPTA, ADAPTA-SUPER |
| | GEA Hilge HYGIA H III L, L-SUPER |

is in conformity with the following UK-directives, provided that the site conditions for the commissioning are met as specified in the engineering documents, in particular in the operation manual:

Supply of Machinery (Safety) Regulations 2008, 2008 No. 1597

Designated standards used:

EN 809:1998+A1:2009+AC(D) EN ISO 12100:2010

Authorized person for compiling andMichael Kielyhanding over technical documentation:GEA Mechanical Equipment UK Ltd

Michael Kiely GEA Mechanical Equipment UK Ltd Westfalia House Old Wolverton Road, Old Wolverton, Milton Keynes MK12 5PY, United Kingdom

Bodenheim, den 02.11.2022

i.V. D. Aug

Karsten Becker Managing Director

i. V. Dr. Danijel Anciger Manager Product Development

2 Safety

2.1 Intended use

Λ Warning!

Non-intended use!

► Pump only media that are specified in the order. The pump has been specially designed for them.

► Operate the pump only on the electrical grid that was specified in the purchase order.

2.1.1 Pumped fluids

Use only clean or lightly polluted liquids as pumped fluids as long as they do not chemically or mechanically attack the pump materials or reduce their strength. If you want to pump liquids with higher viscosity than that of water, check for possible overload of the motor.

2.1.2 Minimum flow rate

The pump may not be operated below of a flow rate of Q_{min} = 10-15 % Q_{opt} .

2.1.2.1 Minimum flow rates in explosive atmospheres

For pumps used in explosive atmospheres according to EU explosion protection directive 2014/34/EC or *Equipment and Protective Systems Intended for Use in Potentially Explosive Atmospheres Regulations 2016* the minimum flow rates of the ATEX additional instructions in Annex B apply.

2.1.3 Connections and piping

The pipe nominal diameters of the system should be equal to or greater than the pump nominal diameters DNE (suction side) or DNA (pressure side), and the fittings to the pump should match exactly the type standard of the fixed mating connection part on the pump. The suction line must be hermetically sealed and routed such that no air pockets can form. Avoid tight bends and valves directly in front of the pump. On the suction side, a straight settling section with a minimum length of 5 times the pipe diameter should be provided. The suction head of the system must not be larger than the suction head guaranteed by the pump.

2.1.4 Switching frequency

Do not exceed a switching frequency of 15 switching operations per hour.

2.1.5 Types

All information and descriptions in these operating instructions on the use and handling of the pumps refer exclusively to the standard versions. Special designs and customised deviations as well as random external influences in the use and operation are not included in this provision.

2.1.6 Hygiene classification

The pump is suitable for hygienic processes. It must not be used in aseptic processes.

2.2 Safety precautions in these operating instructions

Read the safety precautions!

These operating instructions contain basic precautions that must be observed during installation, operation and maintenance. They must therefore be read by the installer and relevant personnel or operator prior to installation and commissioning. The operating instructions must always be available at machine/ system site.

In addition to the general safety precautions listed in this chapter on safety, be sure to read also the other, special safety precautions included.

2.3 Explanation of the safety symbols used

🚹 Danger

Stands for an immediate danger which leads to heavy physical injuries or to the death.

Description to avert the danger

\land Warning!

Stands for a possibly dangerous situation which leads to heavy physical injuries or to the death.

Description to avert the dangerous situation.

▲ Caution!

Stands for a possibly dangerous situation which could lead to light physical injuries or to damages to property.

Description to avert the dangerous situation.

Notice

Stands for an important tip whose attention is important for the designated use and function of the product.

► Description of the necessary action for proper operation of the product.

2.4 Safety instructions for the company/operator

Follow the safety instructions contained in this operating manual, the relevant national accident prevention regulations as well as any internal working, operating, and safety provisions of the operating company.

Marning!

Hot or cold machine parts

Risk of burns.

Secure hot or cold machine parts against contact!

Marning!

Rotating machine parts

Hazard of entrapment or entanglement.

- ► Do not remove contact protection for rotating machine parts (e.g. coupling)!
- Replace defective safety devices promptly!

<u> Marning!</u>

Hazardous materials

Contact with dangerous substances, e.g. by inhalation.

- ► Discharge the leakage of dangerous goods such that no danger to persons and the environment arises!
- Comply with legal provisions!
- Switch off the pump in the event of failure of the mechanical seal.
- Replace the mechanical seal before next use!

🕂 Warning!

Tripping and falling hazard

Danger due to electrical cables.

► Route the electrical supply line such that there is no risk of tripping (only for pumps on a chassis).

🛕 Danger

Live parts

Electric shock by touching live parts

► Use only technically flawless plugs and cables.

2.4.1 Dangers of non-compliance with safety information

Ignoring the safety instructions can result in bodily harm to persons as well as environmental harm and machine damage.

Failure to follow the safety instructions will result in the loss of any claims for damages.

Failure to follow the instructions may entail the following hazards, for example:

- Failure of important functions of the machine/system.
- Failure of prescribed methods for repair and maintenance
- Exposure of persons to electrical, mechanical, and chemical hazards.
- Environmental risks caused by leakage of hazardous substances.

2.4.2 Safety-conscious work behaviour

Follow the safety instructions contained in this operating manual, the relevant national accident prevention regulations as well as any internal working, operating, and safety provisions of the operating company.

2.5 Unauthorised modification and ordering of spare parts

Modification or alteration of the machine is only permitted with the written permission of the manufacturer.

Exclusive use of original spare parts and accessories authorised by the manufacturer ensures safety. The manufacturer will bear no liability for consequences arising from the use of unauthorised parts.

2.6 Staff qualifications and training

The staff for working on and with the pump must have the appropriate qualifications. Responsibilities, competencies and supervision of staff must be clearly defined by the operating company. If personnel do not have the necessary knowledge, they are to be trained and instructed. If necessary, this can be done by the product manufacturer/vendor on behalf of the operating company. The operating company must also ensure that the contents of the operating instructions are fully understood by the staff.

2.7 Safety equipment

Do not remove instructions from the pump.

Signs attached directly on the machine, such as an arrow to indicate the direction of rotation, must absolutely be observed and kept in fully legible condition. Damaged or illegible signs must be replaced.

2.8 Possible residual hazards



Despite careful design of the machine and the implementation of all safety-relevant regulations, further risks for persons and machine during all life phases of the pump cannot be fully ruled out. The additional safety instructions in the individual chapters of this manual must therefore be carefully observed!

The residual risks that were ascertained during the risk assessment carried out for the product according to safety standard EN ISO 14121 - Safety of Machines - are:

- mechanical hazards due to sharp sheet metal edges and projecting parts
- electrical hazards as a result of inadvertently coming in contact with terminals and cables
- thermal hazards as a result of inadvertently coming in contact with pump housings and pipes
- exposure to noise
- hazards caused by vibration due to improper installation
- hazards due to working materials and other materials in case of allergies or the like.
- neglect of ergonomic principles
- combinations of various hazards
- unexpected starting, unexpected rotation in case of wrong electrical connections or defects
- shut down, emergency stop when defects are detected
- changes to the rotational speed
- power failure
- Hazard from insufficient / incorrect cleaning Product contamination,

- failure of the control circuit or control loop
- incorrect assembly
- fracture during operation
- operating media or objects getting thrown out
- loss of stability
- personnel slipping, tripping or falling

3 Description

3.1 Pump overview




Fig.1

0130.00 - Annular casing 0153.00 - Suction port 0156.00 - Discharge port 0180.01 - Dome carrier 0340.00 - Motor stool 0680.00 - SUPER shroud 0801.00 - Motor

3.2 Description

The pump is a end suction, single-stage centrifugal pump in system block design. All wetted parts are based on the "hygienic design" guidelines. The material quality 1.4404 and the respective design standard are executed according to the order and, if desired, verified with a certificate.

3.2.1 Standard version applications

The standard version of the pumps is used in the following areas:

- Breweries (beer, wort, mash, yeast, etc.)
- Dairies (milk, milk mixes, cheese production, etc.)
- Soft drinks (fruit juice, lemonade, mineral water, etc.)
- Wine and sparkling wine production
- Distilleries (mash, distillates, etc.)
- Food production (marinades, pickle, cooking oil, etc.)

- Cleaning systems (CIP)

3.2.2 Hygienic design applications

Due to the consistent hygienic design and the use of pore and porosity-free materials, the pump is ideally suited for use in the following areas:

- pharmaceutical industry
- medical technology
- in biotechnology process plants

Special applications arise in the area of ultrapure water delivery/WFI, as well as in equipment for the production of parenterals and infusion solutions according to FDA.

3.3 Pump name

| GEA Hilge pump name | | | | | |
|---------------------|------|-------------|---------------|----------------|-----------------|
| GEA Hilge HYGIA H | III | L | 80/80 | 55 | 2 |
| Pump name | Size | Design type | Nominal width | Output [kW] | Number of poles |

3.4 Typenschild

The following information is given on the name plate:

| Pump-Type: Pumpenbezeichnung | P: Motorleistung |
|------------------------------|---------------------------|
| SerNo.: Seriennummer | n: Drehzahl |
| Q: Fördermenge | TAG No.:Kundenbezeichnung |
| H: Förderhöhe | YOM: Herstellungsjahr |

4 Transport and Storage

4.1 Special personnel qualification for transport and storage

Transports may only be carried out by qualified staff, who must observe the safety instructions.

4.2 Safety precautions for transport and storage

\land Warning!

Falling loads

Danger from falling loads.

► To transport the pump, use suitable lifting gear with sufficient carrying capacity.

- ► Make sure that there are no persons present under suspended loads.
- ► Make sure that the pump is horizontally aligned when lifting.

\land Warning!

Wrong attachment points!

- ► Attach the rope to suitable anchor points.
- ► Never fasten a rope to the pump housing or the suction/pressure port!
- ► For version with casing: Remove the stainless steel casing before
- transport.




Fig.2: Anchor points (example)

Storage of the pump



Frost

Risk due to external conditions.

▶ In case of frost risk, drain the pump completely.

If the pump is not used immediately, proper storage conditions are as important for later operation as careful installation and proper maintenance.

Protect the pump from cold, moisture and dust, as well as against mechanical influences.

Qualified personnel is required for proper installation and maintenance.

4.3 Dimensions / weights

| Weights [| Weights [kg] HYGIA H III L | | | | |
|-----------|----------------------------|------|------------|-------------------------|--------------------|
| P2 [kW] | Pole | IEC | Motor foot | Cup-shaped feet carrier | SUPER-Dome carrier |
| 22 | 2 | 180M | 321 | 331 | 347 |
| 30 | 2 | 200L | 347 | 366 | 390 |
| 37 | 2 | 200L | 362 | 381 | 405 |
| 45 | 2 | 225M | 450 | 466 | 489 |
| 55 | 2 | 250M | 524 | 550 | 580 |

4.4 Unpacking the pump

All of our pumps leave our warehouse properly packaged to avoid damage in transit.

Should you nevertheless find any damage after cautious unpacking and exact inspection of the shipment, immediately notify the carrier (railway, post, freight forwarder, shipping company). Make claims for damages. The transport risk passes to the customer once the shipment has left our warehouse.

4.5 Disposal of packaging material

The generation of waste should be avoided or minimized wherever possible. Surpluses and packaging materials not suitable for recycling should be disposed of through an approved waste disposal company. Packaging materials not suitable for recycling must always be disposed of in accordance with the requirements of environmental protection and waste disposal legislation as well as the requirements of the local authorities.

Packaging materials suitable for recycling should be reused or reprocessed.

5 Technical data

The operating safety of the delivered machine is only guaranteed if the machine is used as intended according to the sections of the operating instructions and the purchase order.

\land Warning!

Overload of the pump!

► Do not operate the pump above the maximum permissible operating data.

► Avoid even short-term pressure overloads (e.g. by pressure surges).

5.1 Serial number

The pump can be uniquely identified by the serial number. When ordering spare parts, always quote the serial number. The serial number is indicated on the nameplate.

5.2 Performance data

The performance data - delivery head and flow rate - are explained in accordance with ISO 9906: 2012, Grade 3B and documented with the acceptance report.

5.3 Noise emissions

Measured values in accordance with DIN EN ISO 3746 for pump units, measuring uncertainty 3 DB(A).

| Noise emissions HYGIA H L | | |
|---------------------------|---------------------------------|--|
| Motor output [kW] | L _{pfa} [dB(A)] 2-pole | |
| 22.0 | 80 | |
| 30.0 | 80 | |
| 37.0 | 80 | |
| 45.0 | 80 | |
| 55.0 | 80 | |

The noise emissions caused by a pump are influenced mainly by its application. The values shown here should therefore be considered merely as a guide.

5.4 Maximum operating temperatures

Warning!

Exceeding the maximum temperatures!

Never exceed the specified operating temperatures.

| Operating temperatures | | |
|------------------------|------------|--|
| Design | Temp. [°C] | |
| Normal version | 95 | |
| Sterilisation (SIP) | 140 | |

5.5 Maximum operating pressure

Warning!

Pressure overload of the pump!

- ► Operate the pump according to the ordering data.
- ► Never exceed the specified maximum operating pressures.

| Maximum operating pressure | | |
|----------------------------|----------------|--|
| Design | Pressure [bar] | |
| Normal version | 64 | |

6 Assembly and installation

6.1 Safety precautions for setup, installation, and connection

<u> Warning!</u>

Tipping (tilting) of the pump!

- ► The surface for setting up the pump should be clean, level and have sufficient load-bearing capacity.
- ► Bolt the provided fastening points to the foundation for proper setup of the pump according to the usual rules of mechanical engineering.

Marning!

Mechanical overload!

► Do not use the pump and its connection port as support for the piping. (EN 809 5.2.1.2.3 and EN ISO 14847).

► Follow the general rules of mechanical engineering and plant construction and the regulations of the manufacturers of connecting elements (e.g. flanges). These regulations may include information on tightening torques, max. permissible angular misalignment, tools/equipment to use.

- ▶ Be sure to avoid any strain on the pump.
- ► After piping, check the alignment of the coupling (where applicable).

▲ Caution!

Overload by foreign objects!

► Before installing the pump in the system, remove all plastic films and caps from the connectors.

▲ Caution!

Dry running of the mechanical seal!

- ► The suction line must be hermetically sealed and laid such that no air pockets can form.
- ► Avoid tight bends and valves directly in front of the pump. They impair the incoming flow of the pump and the NPSH of the system.

► The suction head of the system must not be larger than the suction head guaranteed by the pump.

► The piping nominal diameters of the system should be equal to or greater than the DNE or DNA connections of the pump.

► For suction operation, install a foot valve.

► Route the suction line in ascending direction and the supply line at a slight slope towards the pump.

► If the local conditions do not permit a continuous ascent of the suction line: Provide a vent at its highest point.

- ► Install a shut-off valve in the supply line close to the pump.
- Open the suction side shut-off valve completely during operation.
- Do not use the suction side shut-off valve for controlling.
- ► Install a shut-off valve in the pressure line close to the pump. This can be used to control the flow rate.

<u> Warning!</u>

Overheating!

- Ensure adequate ventilation.
- Avoid sucking in the heated exhaust air also of adjacent units.
- Maintain minimum distances.

▲ Caution!

Vibration!

► Ensure stable construction for mounting of the pump and piping. Insufficiently stiffened substructures may cause an overall structure capable of oscillating, which is excited to oscillate by hydraulic and/or motor forces during changing operating conditions in the system.

▲ Caution!

Dry running of the mechanical seal with double mechanical seal!

► Always connect the flushing lines such that supply for flushing is always ensured.

► In a tandem arrangement, make sure that the pressure does not exceed 0.2 bar.

► Always keep the level in the liquid tank between the upper and the lower mark (where applicable).

🚹 Danger

Electric shock by touching live parts!

- ► Have the electrical connections be made by a licensed electrician.
- ► Follow the VDE as well as local regulations, in particular the safety regulations.

<u> A</u> Danger

For motors with frequency converter (tronic): Electric shock by touching live parts!

► Even if the power supply is switched off, touching electrical parts may cause an electric shock.

► Disconnect the power supply and wait at least four minutes before touching electrical components.

\land Warning!

Electric overload!

► Compare the voltage indicated on the motor plate with the operating voltage. The power supply properties must match the specifications on the nameplate.

► Install a motor protection switch.

▲ Caution!

Voltage spikes in frequency converter operation!

- ► Use a motor suitable for frequency converter operation.
- ► Use a dU/dt filter to avoid voltage spikes or a motor with reinforced windings.

▲ Caution!

Dry running of the mechanical seal when checking the direction of rotation.

- ► Fill and vent the pump before checking the direction of rotation.
- ► Ensure that the flushing system (with double mechanical seal, tandem) rinses the mechanical seal.
- ► Switch on the motor only briefly (1-2 seconds). Note the direction-of-rotation arrow on the pump.

6.2 Special personnel qualification

The personnel used for setup, installation and connection must be adequately qualified for this work. See also Section 2.6, Page 16.

6.3 Setup, installation, and connection

6.3.1 Checking smooth running of the impeller

Before installation, check that the impeller is running smoothly. Perform the following steps:

- 1. Remove the motor shroud (only for SUPER version).
- 2. Remove the motor fan cover.
- 3. Note the pump's direction of rotation (arrow).
- 4. Carefully rotate the shaft of the impeller.

The shaft should be easy to rotate. If the impeller rubs against something, it has some damage that may have happened during transport of the pump. In case of rubbing of the impeller: Contact the HILGE service. If the impeller rotates freely:

- 5. Reattach the motor fan cover.
- 6. Reattach the motor shroud (only for SUPER version).
 - \rightarrow The impeller has been checked for running smoothly.

6.3.2 Setting up and aligning the pump unit

The pump is designed for horizontal operation and may only be operated in this position.




Fig.3: Permissible setups of the pump

Aligning the pump:

- 1. Level the unit via the machined planar surfaces of the ports using a machine spirit level.
- 2. After aligning the unit, tighten the fastening screws evenly in a crosswise sequence (where applicable).
 - \rightarrow The pump unit has been set up and aligned.

6.3.3 Installation in the piping system





Fig.4: Installation in the piping system top: Inlet operation | bottom: Suction operation | P - Pump | M - Motor

6.3.3.1 Space requirements

Maintain the following minimum distances. Pay attention to motor performance.

Horizontal installation



6.3.3.2 Noise and vibration damping

To achieve optimum performance and to minimize noise and vibration, it is recommended to provide the pump with vibration dampers.


In general, this should always be considered for pumps with motor sizes starting from 11 kW. But unwanted vibrations and noises occur also with smaller motor sizes.

Noise and vibration are caused by the rotating parts in the motor and the pump and by the flow in the pipes and fittings.

The effect on the environment is subjective and depends largely on the correct installation and the nature of the rest of the system.

Foundation

Vibration damping is best achieved if the pump is set up on a flat, solid concrete foundation.



As a guideline, the concrete foundation should be 1.5 times as heavy as the pump.

Vibration damper

To avoid the transmission of vibrations to the building, it is recommended to disconnect the pump foundation from parts of the building using vibration dampers.

Selecting the correct vibration damper requires the following data:

- Forces transmitted via the vibration damper
- Motor speed, if necessary, taking into account a speed control
- Required damping in % (suggested value: 70 %)

The correct damper depends on the respective installation. An incorrectly designed damper may even increase the vibration. Vibration dampers should therefore be designed by the vendor of the vibration damper.

Compensators

If the pump is mounted on a foundation along with vibration dampers, be sure to install compensators at the pipe connections. This prevents the pump from "hanging" in the connections.

Compensators are installed to

- absorb expansion/shrinking in the piping caused by varying fluid temperatures;
- reduce mechanical stress occurring in conjunction with pressure surges in the system;
- absorb noise caused by the system in the piping (only rubber ball compensators).

Note: Compensators must not be used to compensate for inaccuracies in the piping, for example, to compensate for an offset in the centre of the connections.

Install the compensators both on the suction side and pressure side at a minimum distance to the pump, which is 1-1.5 times the nominal diameter of the piping. This allows for an improved flow on the suction side of the pump, as well as reduced pressure drop on the pressure side.

For connections with a size over DN 100, we always recommend compensators with length limiters.

The pipes must be started so that they can cause no strain in the compensators and in the pump. Follow the manufacturer's instructions and hand them over to the person responsible or to the plant manufacturer.

Vibration may cause the following damage:

- Damage to roller bearings of pump and motor
- Damage to the mechanical seal
- Increased coupling wear
- Damage to shaft/hub connections
- Cracks on pump ports
- Loosening of screw connections
- Cable breaks in the motor connection
- Contacting of pump impellers.

6.3.4 Using the mechanical seal

For perfect operation, mechanical seals require a lubrication film in the sealing gap, which prevents contact between the two sliding surfaces. Usually this lubrication film is formed by the pumped product or by an externally supplied flushing/sealing fluid.

Due to the friction heat between the sliding faces, the lubrication film evaporates towards the atmosphere. This means there is a leak that is invisible in water, water-like or volatile liquids (e.g. alcohol). The amount of leakage for faultless operation is usually only a few ml/h; however, it may multiply depending on other influences.

Particularly in the running-in phase, mechanical seals, regardless of size, type or design, are subject to low leakage. In individual cases, it may be necessary to tolerate a low, visible leakage or to counteract it with suitable measures.

Dry run

The mechanical seal needs a lubrication film between the sliding surfaces for correct sealing.

If the lubrication film is missing or interrupted between the sliding surfaces, dry running occurs. The friction heat generated by the direct contact of the sliding surfaces leads to the destruction of the mechanical seal. Depending on the material pairing, this can take place within a few seconds.




Fig.7:Lubrication film between the sliding surfacesP - Pump side | A - Atmosphere side | L - Lubrication side | 0433.00 - Mechanical seal

6.3.5 Flush connections for double mechanical seals (optional)

6.3.5.1 Flushing fluid (optional)

Requirements of the flushing fluid

The flushing fluid has the task to lubricate and cool the product-side mechanical seal and the radial packing ring on the atmospheric side.

The flushing fluid must meet the following criteria:

- good flowability
- no impurities
- no solids
- no dissolved components
- adequate thermal conductivity


- no chemical or mechanical attacking of the pump materials, sealing materials, and elastomers.
- No contaminating of the pumped fluid
- Viscosity < 5 mPas
- Water hardness < 5° dH

Demineralised water meets these requirements to a large extent.

6.3.5.2 Double mechanical seals (optional)

Pumps with double-acting mechanical seals are equipped with a seal cartridge. This seal cartridge holds the sealing or flushing fluid, depending on the seal version. The connections for flushing must be made as shown. Only in this way can the flushing fluid flow effectively around the mechanical seal.

The flush ports (A and B) run vertically through the openings of the motor stool 0340.00.



Connecting the flushing

- 1. Connect the inlet line (A).
- 2. Connect the outlet line (B).
- 3. Check correct fit of the connections.
 - \rightarrow The flushing has been connected.

Double mechanical seal - tandem arrangement (optional)

Flushing fluid

To maintain their function, mechanical seals need a flushing fluid, which has the following tasks, including others:

- Dissipation of any leakage
- Protection against dry running
- Lubrication and cooling of the mechanical seals

A clean liquid, compatible with the pumped fluid, is used as the flushing medium.

Ensuring the flushing operation

- 1. Open the inlet of flushing fluid.
- 2. Vent the seal cartridge.
- 3. Ensure pressureless circulation.

 \rightarrow Done.

For abrasive media, use lost flushing in which the flushing fluid is discharged directly.

Permissible supply pressures and temperatures

The supply of the mechanical seal with flushing fluid must be unpressurised. The maximum overpressure must not exceed 0.2 bar. When using a pass-through flushing, secure the flushing fluid connection with a pressure reducer or similar if necessary.

When using a closed flushing circuit with a supply reservoir, regularly monitor the fill level (visually or by means of level probes). Also, make sure that no pressure build-up can occur in the flushing circuit. Keep the reservoir open to the atmosphere. Change the flushing fluid regularly when using critical media.

The maximum temperature of the flushing fluid must be 20 K below the boiling temperature of the flushing fluid at the outlet. The temperature rise in the pump flushing chamber is normally less than 10 K (inlet/outlet). The maximum permissible operating temperatures of the flushing device must not be exceeded.

6.3.6 Electrical connection

<u> A</u> Danger

Electric shock by touching live parts!

- ► Have the electrical connections be made by a licensed electrician.
- ► Observe local laws, standards and regulations especially safety precautions.

6.3.6.1 Star connection

Star connection for high voltage.

Connect the pump according to the ordering information. The following figure shows the wiring diagram of the star connection.




Fig.9: Star connection

6.3.6.2 Delta connection

Delta connection for low voltage.

Connect the pump according to the ordering information. The following figure shows the wiring diagram of the delta connection.




Fig.10: Delta connection

6.3.6.3 Frequency converter operation

All three-phase motors can be connected to a frequency converter. Frequency converter operation may subject the insulation of the motor to a higher load so that louder motor noise than in the normal case may occur due to eddy currents caused by voltage spikes.

Large motors driven by a frequency converter are loaded by bearing currents. For pump motors that are used with an external frequency converter, HILGE recommends the use of insulated motor bearings for sizes of 37 kW and above to avoid increased wear of the motor bearings by possible bearing currents.

Check the following operating conditions if the pump is operated using a frequency converter:

| Operation with frequency converter | | |
|---|---|--|
| Operating conditions | Measures | |
| Noise-sensitive applications | Install a dU/dt filter between the motor and frequency converter (reduces voltage spikes and thus noise). | |
| Particularly noise-sensitive applications | Install sinusoidal filter. | |
| Cable length | Use a cable which satisfies the conditions prescribed by the manufacturer of the frequency converter. | |
| Supply voltage up to 500 V | Check that the motor is suitable for frequency converter operation. | |

| Operation with frequency converter | | |
|--|--|--|
| Operating conditions | Measures | |
| Supply voltage between 500 V and 690 V | Install a dU/dt filter between the motor and the frequency converter (reduces voltage peaks and thus noise), or check whether the motor has a reinforced insulation. | |
| Supply voltage 690 V and above | Install a dU/dt filter between the motor and the frequency converter and check whether the motor has a reinforced insulation. | |

Notice

Incorrect operation of the frequency converter!

► Follow the manufacturer's instructions to install and operate a frequency converter.

6.3.6.4 Checking the direction of rotation after connecting

Perform the following steps:

- 1. Re-install all safety devices.
- 2. Check that hydraulic connections are firmly secured.
- 3. Open stop valves.
- 4. With double mechanical seal in tandem arrangement, connect the flushing fluid (see Section 6.3.5, Page 30)
- 5. Fill the pump (system).
- 6. Note the direction-of-rotation arrow on the pump.
- 7. Switch on the motor briefly (1-2 seconds).
- 8. Compare the direction of rotation with the specified direction (arrow).
- 9. Correct the connection if necessary.
 - \rightarrow The direction of rotation has been checked, and corrected if necessary.

6.3.6.5 Earthing

<u> Warning!</u>

Electrical voltage by different potentials.

The occurrence of potential differences can cause damage to persons and property.

► Properly earth the pump and motor to achieve potential equalisation.

Earthing the motor

Equipotential bonding for the motor is performed via the protective conductor connection in the terminal box.

Earthing the motor shroud

Equipotential bonding of the motor shroud is achieved using a suitable earthing cable. Connect the earthing cable on the side of the motor shroud using the provided hole (A) and connect it with the earthing conductor.




Fig.11: Earthing connection of the motor shroud

Ground the assembly (foot)

Equipotential bonding of the assembly is achieved via the screw connection to the motor. Use toothed lock washer at corresponding position for grounding.

Earthing the machine pad support

Equipotential bonding of the machine pad support is achieved via the screw connection to the motor. Use a toothed washer at the appropriate position (B).




Fig.12: Earthing the machine pad support

7 Commissioning

7.1 Special personnel qualification

The commissioning personnel must be suitably qualified for this work. See also Section 2.6, Page 16.

7.2 Safety instructions for commissioning

▲ Caution!

Hazard due to overheating and pressure overload!

► Never pump for longer than 30 seconds against a closed shut-off device. Pumping against a closed shut-off device leads to rapid warming of the pumped fluid and pressure increase.

► Do not exceed the permissible operating temperatures.

7.3 Commissioning / initial startup

7.3.1 Checking conditions of use

Compare the information in the following documents with the intended conditions of use of the pump:

- Order documents (order confirmation)
- Nameplate
- Operating instructions
- Test bench acceptance
- Make sure that the pump is operated only under the specified conditions of use. These conditions apply to pressure, temperature, fluid, etc.

7.3.2 Commissioning of the pump

Perform the following steps:

- 1. Check that all connections are firmly secured.
- 2. Make sure that all safety devices are installed.
- 3. Make sure that the electrical connections are correct.
- 4. Open stop valves in the system.
- 5. Fill the pump along with the system.
- 6. Vent the pump along with the system.
- 7. For double mechanical seal in tandem arrangement, connect the flushing fluid. For details, see Section 6.3.5, Page 30.
- 8. Fully open the suction-side stop valve.
- 9. Close the pressure side stop valve.
- 10. Switch on the pump.

11. Slowly open the pressure side stop valve.

 \rightarrow This completes the commissioning.

If there is no increase of delivery head after commissioning:

- 1. Switch off the pump.
- 2. Again vent the pump (system).
- 3. Repeat steps 6 to 9, and follow Section 10.3, Page 47.

7.3.3 Functional testing of the mechanical seal

Perform the following steps:

1. Inspect the pump and check whether liquid exits at the mechanical seal. An intact mechanical seal operates virtually without any leakage.

If pumped fluid or flushing fluid exits:

- 1. Switch off the pump.
- Replace the mechanical seal.
 Follow the installation instructions Section 10.2, Page 46.

8 Cleaning

To ensure the quality of sensitive fluids, pumps must be cleaned immediately after each use. Only in this way will adhesions and deposits be removed completely and contamination of the products be prevented. To achieve the best possible results, Hilge pumps are optimised with regard to gap and dead spaces, designed according to DIN EN 13951, and resistant to the cleaning agents referred to in the following chapter. Cleaning is carried out inside the system; no parts need to be removed or dismantled.

In general, a distinction is made between CIP and SIP. The procedures must comply with the state of the art and the EC directives. In any case, the operator must ensure that the target specifications are reached and applied as intended using the cleaning and sterilisation procedures, as well as the working temperatures and steps.

8.1 Special personnel qualification

The cleaning personnel must be suitably qualified for this work. See also Section 2.6, Page 16.

8.2 Safety instructions

<u> Warning!</u>

Damage caused by cleaning agents!

- ► Use only suitable cleaning agents.
- ► Observe the safety instructions in the product descriptions of the cleaning agents.
- ► Use always suitable personal protective equipment when handling cleaning agents.

► Be sure to avoid exceeding the permissible concentrations of cleaning agents.

Reducing acids should not be used, because they cause pitting.

Marning!

Risk of burns!

► Do not touch the pump during cleaning. The surfaces may be very hot.

Warning!

Danger of scalding or burns.

► Do not touch the pump during steam sterilisation and the cooling phase. Surface temperatures may rise to over 100 °C.

▲ Caution!

Dry running of the mechanical seal!

► Do not run the pump during steam sterilisation. Destruction of the mechanical seal!

<u> Warning!</u>

Pressure shock by evaporating liquid!

Completely empty the system before steam sterilisation.

Notice

Disposal of cleaning agents

► Dispose of cleaning agents properly and in an environmentally friendly way.

8.3 CIP

CIP stands for Cleaning in Place, the pump is completely rinsed with cleaning agents. The cleaning agent used must be suitable for the respective cleaning task.

The following table lists approved detergents and disinfectants and their permitted concentrations. Alternatively, information from DIN11483 Part 1 can be used.

| Cleaning and | Cleaning and disinfecting agents | | | | | | | |
|--------------|---|------------------------|-----------------------|-------------------|---|-------------------------------------|--|--|
| Cleaner type | Chemical name | Max. concentration | Max. temperature | Permissible pH | Max. permissible CI content in the preparation water | Max. permissible contact time | | |
| | | [%] | [°C] (°F) | | [mg/l] | [h] | | |
| Alkaline | NaOH | 2.5% | 85 (185) ¹ | 13-14 | 150 | 3 | | |
| p | H ₂ SO ₄ H ₃ PO ₄ HNO ₃ | 2% ^{2,3} | 60 (140) | | 150 ^{2,3} | 1 | | |
| Acid | C ₂ H ₄ O ₃ | 0.0075% | 90 (194) | | 150 | 0.5 | | |
| | C ₂ H ₄ O ₃ | 0.15% | 20 (68) | | 150 | 2 | | |
| | lodophore | 50 mg/l act. Iodine | 30 (86) | >3 | 150 | 3 | | |

Cleaning agents that contain hydrochloric acid (HCl) or hydrofluoric acid (HF) must not be used. Consult the supplier for the use of special cleaning agents and procedures with respect to the materials. Thoroughly rinse the pump with water to remove any cleaning agents leaving no residues. The maximum permissible temperatures can be obtained from the technical data.

¹ Dependent on the maximum permissible temperature of the pump

² CrNi-steels

³ CrNiMo-steels

8.4 SIP

SIP stands for sterilisation in place, in which the pump is sterilised with superheated steam. For steam sterilization or sanitization, minimum temperatures of 121 ° C (250 ° F) must be applied to all wetted surfaces. The maximum permissible temperatures can be obtained from the section technical data.

The pump must not be in operation during steam sterilisation. A cool-down period of at least one hour is required after the SIP process.

8.5 Manual exterior cleaning

Notice

Danger due to cleaning agents.

- ► Follow the manufacturer's instructions when using cleaning agents.
- Wear safety glasses and gloves.
- Dispose of cleaning agent properly.
- ► Do not use a high-pressure water jet to clean the pumps.
- Regular manual external cleaning of the pump unit facilitates proper operation.
- Always check the impermeability of the motor (terminal box, condensation water holes) before each cleaning.
- Clean the outside of the pump with a soft cloth or brush and use warm water if necessary.
- When using a cleaning agent, make sure that it does not attack the surface of the pump unit.
- Remove dust and debris that may clog the fan and cooling fins of the engine.
- Dry cleaning is preferable to wet cleaning.
- The cleaning intervals depend on the degree of contamination.

9 Maintenance / servicing

9.1 Safety instructions for maintenance and repair

Warning!

Improper execution of work!

► Maintenance and inspection should be carried out by authorised and qualified personnel.

Marning!

Hot system and pump parts.

► Always allow the pump to cool before maintenance.

\land Warning!

Missing protection and safety devices.

► After completion of work: Reinstall all protective and safety devices and put into operation.

9.2 Special personnel qualification

The maintenance personnel must be suitably qualified for this work. See also Section 2.6, Page 16.

9.3 Pump maintenance

9.3.1 Inspections

The pump is maintenance-free for the most part.

In order to prevent possible malfunctions, GEA recommends that regular visual inspections be carried out. Special attention should be paid to the leak tightness and the correct functioning of the pump.

In order to ensure maximum operational safety of the pump wear parts, such as the mechanical seal and O-rings, should be checked after 2000 hours of operation and replaced if necessary.

In addition, the screw connection of the casing and the clamping shaft should be checked.

In any case, all seals must be checked and, if necessary, replaced during disassembly of the pump.

9.3.1.1 Replacement of O-rings

Notice

Hygiene risk, food safety

Worn out and not fully functional components may lead to the contamination of the pump.

► Pay close attention to the condition of the O-rings during regular inspections.

The O-rings must be replaced if any one of these characteristics are visible:

- The O-ring is deformed at one or more locations.
- The O-ring has cracks.
- The surface of the O-ring is porous and brittle.
- The O-ring has lost its elasticity.

9.3.2 Maintenance intervals

To ensure the highest operational reliability, all wearing parts should be replaced at longer intervals.

The actual maintenance intervals can only be determined by the user since they depend on the operating conditions, for instance:

- · daily period of use,
- switching frequency,
- type and temperature of the product,
- type and temperature of the cleaning solution,
- ambient conditions.

| Maintenance Intervals | | | | | |
|---|---|--|--|--|--|
| Applications | Maintenance intervals (guideline values) | | | | |
| Media at temperatures of 60 °C to 130 °C (140 °F to 266 °F) | approx. every 3 months | | | | |
| Media at temperatures of < 60 °C (< 140 °F) | approx. every 12 months | | | | |

9.4 Maintenance of the L-bearing

9.4.1 Structure of the L-bearing

The bearing consists of a grooved ball bearing 0321.00.

The grooved ball bearing forms the bearing on the motor side to absorb radial forces..

Grease quantities for roller bearings during installation

The information refers to a complete filling of the bearings.

| Grease quantities for installation[?] | | | | | |
|---------------------------------------|---------|--|--|--|--|
| Part no. | 0321.00 | | | | |
| Number of bearings | 1 | | | | |
| Volume [cm ³] | 9 | | | | |
| Quantity [g] | 8.5 | | | | |

9.4.2 Bearing replacement

Replace the bearings after approx. 15,000 to 20,000 hours of operation to ensure trouble-free pump operation.

9.4.3 Premature bearing replacement

In case of continuous wear-promoting external influences such as

- dust
- splash water
- aggressive ambient air
- bearing temperature above 70 °C with standard grease (UNIREX N3)
- bearing temperature above 100 °C up to 120 °C with hot bearing grease (OKS 4200)

we recommend replacing the bearings after approximately 5,000 operating hours.

9.4.4 Grease filling

In the factory, the cavities between the rolling elements are completely filled with grease. The grease is encapsulated by the deflector (0507.05) and is designed as grease filling for normal environmental conditions. Refer to the following chapters for the grease quantities during installation.

The contact surface of the deflector (0507.02) must be greased after approximately 1,500 operating hours, and replaced if damaged.

9.4.4.1 Roller bearing greases

For the lubrication of roller bearings, use the listed roller bearing greases or established equivalents.

| Roller bearing greases | | |
|---|---|---|
| | Storage temperature <70 °C Delivery fluid -1095 °C | Storage temperature > 70 °C / < 100 °C Delivery fluid 96 °C190 °C |
| Factory-filled grease | UNIREX N3 | OKS 4200 |
| Basic oil type | Mineral oil | Polyalfaolefin |
| Thickener | Lithium complex soap | Bentonite |
| Continuous limit temperature | approx. 70 °C | approx. 115 °C |
| Identification acc. to DIN 51502 | K3N-20 | KHCF2R-10 |
| | Key to symbols | Key to symbols |
| Grease type for roller bearings according to DIN52825 | K also permitted: KP= K with EP/AW (additives) KF= K with solid lubricants, e.g. MoS2 (additives) | KHCF HC = Synt. hydrocarbons (base oil type) F= solid lubricants, e.g. MoS2 (additives) |
| NLGI class | 3 | 2 |

| Roller bearing greases | | | | | |
|-------------------------|--|--|--|--|--|
| | Storage temperature <70 °C Delivery fluid -1095 °C | Storage temperature > 70 °C / < 100 °C Delivery fluid 96 °C190 °C | | | |
| Upper usage temperature | N= 140 °C also permitted: P = 160 °C R = 180 °C | R = 180 °C also permitted: P = 160 °C S = 200 °C | | | |
| Lower usage temperature | 20 = -20 °C also permitted: 30 = -30 °C | 10 = -10 °C also permitted: 20 = -20 °C 30 = -30 °C | | | |

9.5 Maintenance of the motor

Motors without grease nipple

Motors without grease nipple are equipped with lifetime lubrication. The grease life then depends on the bearing life. Prerequisite is that the motor must be used according to the specifications in the catalogue.

Motors with grease nipple

On motors with grease nipple, the specifications for relubrication, type of grease, grease quantity, and other information as applicable are given on the lubrication or nameplate.




Fig.13: Lubrication information plate of MGE motor (example)

| Bearing on drive side |
|-------------------------|
| Type of grease |
| Ambient temperature |
| Ambient temperature |
| Bearing, not drive side |
| Grease grade |
| Lubricating interval |
| Lubricating interval |
| |

Note: The nameplate may differ from the presented layout.

10 Malfunctions / repairs

10.1 Special personnel qualification

The troubleshooting / repair personnel must be suitably qualified for this work. See also Section 2.6, Page 16.

10.2 Safety instructions

\land Warning!

Improper execution of work!

► Repair work should be carried out by authorised and qualified personnel.

🛕 Danger

Electric shock by touching live parts!

Always disconnect the pump from power before troubleshooting.

🛕 Danger

For motors with frequency converter (tronic): Electric shock by touching live parts!

► Even if the power supply is switched off, touching electrical parts may cause an electric shock.

► Disconnect the power supply and wait at least four minutes before touching electrical components.

🛕 Danger

Liquids squirting out under high pressure!

► Always depressurise the pump before troubleshooting.

\land Warning!

Hot system and pump parts!

Always allow the pump to cool before troubleshooting.

<u> Marning!</u>

Inadvertent switch-on of the pump!

▶ Be sure to secure the pump against accidental switch-on.

/ Warning!

Contact with dangerous substances (e.g. by inhalation).

► Decontaminate a pump that delivers harmful media.

\land Warning!

Missing protection and safety devices!

► After completion of work: Reinstall all protective and safety devices and put into operation.

<u>∧</u> Caution!

Unsuitable tools!

- ► Make sure that all the parts can be mounted without damage.
- ► Use GEA Hilge assembly tools.

10.3 Malfunctions and remedies

| Malfunction | Са | JSe | Remedy | | |
|---|--|--|----------|--|--|
| Pump does not deliver or pump delivers with | 1. | 2. Incorrect direction of rotation. | | Check electrical connection, and correct if necessary. | |
| inadequate power. | 2. 3. | | | Change phases of power supply (swap motor poles). | |
| | 4. | Back pressure too high. | 3. | Vent and prime suction pipe or pump. | |
| | 5. | Suction head too high, NPSH system (supply) too low. | 4. | Reset operating point according to the data sheet. Check system for contamination. | |
| | 6. 7. | Lines clogged or foreign bodies in the impeller. Air inclusion due to defective seal. | 5. | Raise suction side liquid level, fully open the stop valve in the suction line. | |
| | | | 6. | Open pump and eliminate malfunctions. | |
| | | | 7. | Check and, if necessary, replace pipe seals, pump housing seals and shaft seals. | |
| Motor protection switch turns off, | 1. | Pump is blocked due to clogging. | 1. | Open pump and eliminate malfunctions. | |
| motor is overloaded. | 2. | Pump is blocked by contacting due to strain on the pump body via the piping. (Check for damage.) | 2. | Install pump without strain, support piping by fixed points. | |
| | 3. | Pump runs beyond its rated operating point. | 3. | Adjust operating point according to data sheet. | |
| | 4. | The fluid density or viscosity of the liquid is higher than stated in the order. | 4. | If a lower power than specified is sufficient, reduce the flow rate on the pressure side: otherwise use a | |
| | 5. Motor protection switch is not set properly | Motor protection switch is not set properly | 5. | more powerful motor. Check the setting, replace the motor protection | |
| | 6. | Motor runs on 2 phases. | 0. | switch if necessary. | |
| | | | 6. | Check electrical connection, replace defective fuse | |
| Pump causes too much noise. Pump runs | 1. | Suction head too high, NPSH system (supply) too low. | 1. | Raise suction side liquid level, fully open the stop valve in the suction line. | |
| unevenly and | 2. | Air in suction line or pump. ¹ | 2. | Vent and prime suction pipe or pump. | |
| vibrates. | 3. | Back pressure is less than indicated. | 3. | Adjust operating point according to data sheet. | |
| | 4. | Impeller is unbalanced. | 4. | Clean, check and balance the impeller. | |
| | 5. | Worn internal parts. | 5. | Replace parts. | |
| | 6. | Pump is strained (start-up noise - check for damage.) | 6. | Install pump without strain, support piping by fixed points. | |
| | 7. | Bearings are damaged. | 7. | Replace bearings. | |
| | 8. | Bearings have too little, too much or inappropriate lubricant. | 8. 9. | Add, reduce or replace lubricants. Replace the fan motor. | |
| | 9. | Motor fan defective. | | Open and clean the pump (for self-priming pumps | |
| | 10. | Foreign material in the pump. | | install a screen if necessary). | |

| Actions for troubleshooting | | | | | |
|--|--|--|-------------------|--|--|
| Malfunction | Ca | use | Remedy | | |
| Leakage at the pump body, connections, | 1. | Pump is strained (causing leaks at the pump body or at the connections). | 1. | Install pump without strain, support piping by fixed points. | |
| mechanical seal, | 2. | Housing seals and connection seals defective. | 2. | Replace housing seals and/or connection seals. | |
| gland or socket seal. | 3. | Mechanical seal soiled or sticky. | 3. | Check and clean mechanical seal. | |
| | 4. | Mechanical seal worn. | 4. | Replace the mechanical seal. | |
| | 5. | Surface of shaft or shaft sleeve shrunk. | 5. | Replace shaft or shaft sleeve, repack gland seal. | |
| | 6. | Elastomer unsuitable for the pumped fluid. | 6. | Use suitable elastomer for pumped fluid and temperatures. | |
| Impermissible temperature increases to | 1. | Air in suction line or pump. Suction head too high, NPSH system (supply) too low. | 1. | Vent and prime suction pipe or pump. Raise suction side liquid level, fully open the stop valve in | |
| pump, bearing | 2. Bearings have too little, too much or inappropriate | - | the suction line. | | |
| support or motor | | lubricant. | 2. | Add, reduce or replace lubricants. | |
| | 3. | Pump with bearing support is strained. | 3. | Install pump without strain, support piping by fixed points. Check coupling alignment. | |
| | 4. | Axial thrust is too high. | | | |
| | 5. | Motor protection switch is defective or not set properly. | 4. | Check the relief holes in the impeller and the split rings at the inlet. | |
| | 6. | . Pressure valve closed. | 5. | Check the setting, replace the motor protection switch if necessary. | |
| | | | 6. | Open pressure valve. | |

10.4 Repair

10.4.1 Repair order

Compliance with legal regulations on occupational safety requires all commercial companies to protect their workers and the people and the environment from harmful impacts when dealing with hazardous substances.

Follow local laws, regulations and guidelines.

Certificate of non-objection

The certificate of non-objection (Section 12.1, Page 71) attached to this document is part of the inspection/repair order. Nevertheless we reserve the right to reject the acceptance of this order for other reasons.

HILGE products and their parts are therefore inspected/repaired only if the certificate of non-objection completed properly and completely by authorised and qualified personnel is submitted.

Pumps that have been operated with radioactive substances are not accepted at all.

If, despite careful emptying and cleaning of the pump, safety precautions are required, the necessary information must be given.

10.4.2 GEA Hilge assembly tool kit

Tools from the GEA Hilge assembly tool kit prevent damage to the mechanical seal during assembly.





Fig.14: GEA Hilge assembly tool kit

10.4.2.1 Contents and use

| Tools in the GEA | A Hilge assembly tool kit | |
|------------------|---|--------------------------|
| Image position | Designation | GEA Hilge HYGIA H III |
| 1a | Mounting sleeve Ø 19 | |
| 1b | Mounting sleeve Ø 28 | • |
| 2 | Spray bottle | • |
| 5 | Extractor for mechanical seal counter ring | • |
| 6 | Klüber paste UH1 96-402 | • |
| 7 | Socket wrench a/f 32 | • |
| 7 | Socket wrench bit a/f 27 | • |
| 8 | Optimol paste TA | • |
| 9 | Socket wrench a/f 24 | |
| 9 | Socket wrench bit a/f 17 | |
| 10 | Screw locking compound Loctite Type 243 | • |
| 12c | Mechanical seal mounting sleeve Ø 28 and Ø 30 | • |
| 12c | Plastic adapter Ø 28 | • |
| 12d | Mechanical seal mounting sleeve Ø 19 and Ø 22 | |
| 12d | Plastic adapter Ø 19 | |
| 14 | T-handle with 1/2" square | • |
| | Complete assembly tool kit | • |

10.4.3 Parts overview



| Parts lis | Parts list HYGIA H III | | | | | | |
|-----------|------------------------|-----------------|------|----------|---------------------|--|--|
| Pcs. | Part no. | Designation | Pcs. | Part no. | Designation | | |
| 1 | 0103.00 | Annular casing | 4 | 0560.07 | Straight pin | | |
| 1 | 0161.00 | Back plate | 2 | 0580.06 | Сар | | |
| 1 | 0230.00 | Impeller | 1 | 0580.15 | Сар | | |
| 1 | 0412.00 | O-ring seal | 10 | 0902.02 | Stud screw | | |
| 1 | 0412.04 | O-ring seal | 10 | 0902.29 | Stud screw | | |
| 1 | 0412.05 | O-ring seal | 10 | 0920.04 | Hexagon nut | | |
| 1 | 0433.00 | Mechanical seal | 10 | 0920.67 | Hexagon nut | | |
| 10 | 0554.80 | Washer | 1 | 0922.00 | Impeller nut | | |
| 10 | 0554.81 | Washer | 1 | 0930.01 | Toothed lock washer | | |
| 1 | 0557.00 | Seal spacer | | | | | |







Fig.16: L-bearing housing

| Parts list L-bearing housing | | | | | | |
|------------------------------|----------|----------------------|------|----------|------------------|--|
| Pcs. | Part no. | Designation | Pcs. | Part no. | Designation | |
| 1 | 0211.00 | Pump shaft | 1 | 0504.09 | Spacer ring | |
| 1 | 0321.00 | Grooved ball bearing | 1 | 0636.00 | Grease nipple | |
| 1 | 0340.00 | Motor stool | 8 | 0914.06 | Hex socket screw | |
| 1 | 0360.00 | Bearing cover | 1 | 0932.01 | Retaining ring | |
| 1 | 0421.00 | Radial packing ring | 1 | 0940.02 | Кеу | |



10.4.5 Parts overview of motor connection and motor

Fig.17: Motor connection and motor

| Parts list motor connection and motor | | | | | | |
|---------------------------------------|----------|--------------------------|--------|----------|--------------|--|
| Pcs. | Part no. | Designation | Pcs. | Part no. | Designation | |
| 1 | 0180.01 | Cup-shaped feet carrier | 4/6* | 0595.00 | Pad | |
| 1 | 0346.00 | Intermediate motor stool | 1 | 0680.00 | Motor shroud | |
| 1 | 0528.00 | Collar bushing | 1 | 0801.00 | Motor | |
| 4/6* | 0554.50 | Washer | 8/4* | 0901.89 | Hex screw | |
| 8/4* | 0554.0A | Washer | 8 | 0901.90 | Hex screw | |
| 8/4/0* | 0554.0B | Washer | 4 | 0901.91 | Hex screw | |
| 8 | 0554.0C | Washer | 4/6* | 0904.20 | Grub screw | |
| 4 | 0554.0D | Washer | 8/4/0* | 0920.09 | Hexagon nut | |
| 2 | 0580.16 | Plug | 4/6* | 0927.08 | Cap nut | |
| 2 | 0580.17 | Plug | | | | |

10.4.6 Disassemble the pump

Disassembly of the pump is carried out in the reverse order of assembly. For this purpose, obtain the work steps from the respective sections in the Maintenance chapter.

10.4.7 Installation instructions

Notice

Hygiene risk, food safety

Incorrect installation of the pump can cause subsequent contamination and thus impair food safety.

- ► Always observe the following instructions:
- Use tools from the HILGE assembly tool kit for installation.
- Check removed parts for damage and wear, and replace if necessary.
 Use only proper, clean parts for installation. Clean installation space and contact surfaces before installation.
- Always use original spare parts.
- Only use certified original spare parts for 3-A applications.
- Use no mineral oil greases for the wet section assembly.
- Always replace mechanical seals completely.
- Handle the mechanical seal with care. Rotary ring and stationary ring are made of fragile material.
- Remember the properties when replacing the O-rings. See Section 9.3.1.1, Page 41
- Use a screw device or an impeller nut mounting device to tighten the impeller nut (0922.00).

10.4.8 Cleaning the components before assembly

Notice

Hygiene risk, food safety

Contaminated components contaminate the pump and installation.

▶ Use suitable chemical cleaning agents to remove impurities in the area of the impeller area, the O-rings or the mechanical seal. Use a brush and / or other tools in order not to damage the surface. Plan contact-free cleaning in an ultrasonic bath to clean the mechanical seal.

10.4.9 Mounting L-bearing housing

i) Hint!

The part numbers stated in the following instructions can be found in the Section 10.4.4, Page 51

Install the L bearing support as follows:

- 1. Push the grease regulator (0647.00) onto the plug-in shaft (0211.00).
- 2. Grease the grooved ball bearing (0321.00). Check the grease quantity in theSection 9.4.1, Page 42.
- 3. Press the grooved ball bearing (0321.00) onto the plug-in shaft (0211.00).

- 4. Mount the spacer ring (0504.01).
- 5. Mount the circlip (0932.01).
- 6. Push the plug-in shaft (0211.00) into the bearing housing (0340.00).
- 7. Mount the bearing cover (0360.00).
- 8. Mount the deflector (057.02).
- 9. Insert the key (0940.02) into the motor shaft.
- 10. Grease the motor shaft end with Klüber paste UH1 84-201.
- 11. Push the mounted motor stool (0340.00) onto the motor shaft. The motor stool (0340.00) must be aligned as follows:
 - With single mechanical seal, leakage drain at the bottom.
 - With double mechanical seal, flush ports top and bottom (through window in motor stool).

The L bearing housing has been installed.

10.4.10 Mounting housing cover

Equipment and tools from the GEA Hilge assembly tool kit

- Loctite Type 243
- Klüber paste UH1 96-402

Connecting the back plate with the bearing housing

Wet the threads of the stud bolts (0902.00) with Loctite Type 243 and screw them by hand (!) into the back plate (0161.00).



Fig.18: Back plate with stud bolts

Grease the seat of the component that borders on the back plate (0161.00) with Klüber paste UH1 96-402.



Fig.19: Contact surface of back plate / structural part

Connect the back plate (0161.00) to the structural part,

using the stud bolts (0902.02), the spring washers (0934.00), and the hex head screws (0920.04). Torque: M10 - 35 Nm, M12 - 80 Nm



Fig.20: Back plate on the structural part

 \rightarrow The back plate is connected with the bearing housing.

10.4.11 Determining the gap size




Fig.21: Gap size HYGIA H

General

The gap size needs to be determined only if modifying/replacing the impeller or the ring housing. The gap between the impeller and the annular casing contributes crucially to complying with the intended use.

Preparation

- 1. Remove the key (0940.00) from the shaft (0211.00).
- 2. Remove the mechanical seal (0433.00) and the O-rings (0412.00) and (0412.05).

 \rightarrow Done.

Determining the air gap (a) Encapsulated mechanical seal

- 1. Push the impeller (0230.00) onto the shaft (0211.00), making sure it does not contact the shaft shoulder. It should be flush with the shaft thread at the front.
- Carefully place the annular casing (0103.00) against the back plate (0161.00). Thus, the impeller (0230.00) is pushed by the annular casing (0103.00) into the zero gap position. The air gap then forms behind the impeller.

- 3. Remove annular casing (0103.00) so that the impeller (0230.00) does not move, retaining its position.
- 4. Screw the impeller nut (0922.00) onto the shaft so that it just touches the impeller without moving it.
- 5. Determine gap a' between the shaft shoulder and the impeller (0230.00) using a feeler gauge or the like.

 \rightarrow The gap size has been determined. Permissible clearance: 4.7 mm - 5.5 mm.

The actual gap size is obtained by subtracting the 4 mm spacer integrated in the encapsulated mechanical seal. If the measured distance a' is less than 4.7 mm, the impeller hub rear (b) must be turned off by this difference.

10.4.12 Installing single mechanical seal




Fig.22: Single mechanical seal

| 0161.00 - Housing cover | 0433.00 - Mechanical seal |
|-------------------------|---------------------------|
| 0211.00 - Pump shaft | 0560.07 - Cylindrical pin |

Features

- Encapsulated spring
- Sealing towards the impeller
- Cylindrical pins for anti-twist protection of the fixed position ring (counter ring)
- Easy to clean
- For adhesive media
- Optimal arrangement in the pump chamber

Equipment and tools from the GEA Hilge assembly tool kit:

- Spray bottle
- Plastic mounting sleeve

Prior to installation

1. Check the shaft and counter ring holder for impurities and damage (sharp edges). If necessary, clean or replace parts.

Notice

Hygiene risk, food safety

Danger due to contamination

- ► Carefully inspect the seat of the mechanical seal.
- ► When installing the fixed position ring (stationary ring) of the mechanical seal, pay attention to the position of the groove and the cylindrical pins.
- Check all O-rings of the mechanical seal for correct seating, and adjust if necessary.

3. Moisten all sliding O-rings with water.

 \rightarrow Done.

Assembly

1. Slide the stationary ring (counter ring) of the mechanical seal (0433.00) along with the O-ring over the shaft into the seat.

On a version with anti-twist protection, the slot and pin positions must match.




Fig.23: Rotary ring, synthetic material assembly aid

2. Push the rotating part of the mechanical seal (0433.00) in the assembled state onto the shaft as far as it will go using a slight rotating motion.



Fig.24: Stationary ring, synthetic material assembly aid

 \rightarrow The mechanical seal has been installed.

i) Hint!

For further assembly information refer to "Installing impeller and housing" section.

10.4.13 Installing the single-flushed mechanical seal

i Hint!

This section applies to the installation of the single-flushed mechanical seal.

Equipment and tools from the GEA Hilge assembly tool kit

- · Spray bottle
- · Plastic mounting sleeve
- Loctite Type 243
- Klüber paste UH1 96-402
- Extractor
- · Socket wrench with plastic insert




Fig.25: Single flushed mechanical seal

| 0161.00 - Housing cover | 0491.00 - Seal cartridge |
|-------------------------------|-----------------------------------|
| 0211.00 - Pump shaft | 0524.01 - Shaft protection sleeve |
| 0412.02 - O-ring seal | 0560.07 - Cylindrical pin |
| 0412.34 - O-ring seal | 0904.22 - Threaded pin |
| 0421.06 - Radial packing ring | 0914.02 - Hex socket screw |
| 0433.00 - Mechanical seal | 0932.09 - Retaining ring |
| | |

Installing the single-flushed mechanical seal

Wet the threads of the stud bolts (0902.00) with Loctite Type 243 and screw them by hand (!) into the back plate (0161.00).

Press the radial packing ring (0421.06) into the seal cartridge (0491.00).

Insert the retaining ring (0932.09) in seal cartridge (0491.00).

Insert the O-ring (0412.02) into the seal cartridge (0491.00).

Press the seal cartridge (0491.00) into the seat of back plate (0161.00).

Connect the seal cartridge (0491.00) with the back plate (0161.00)

Torque: M6: 8 Nm

Screw the threaded pins (0904.22) with one to two turns into the shaft protection sleeve (0524.01) and apply Loctite Type 243.

Insert the O-ring (0412.34) into the shaft protection sleeve (0524.01).

Slide the pre-assembled shaft protection sleeve (0524.01) onto the pump shaft (0211.00) up to the shaft shoulder.

Tighten the pre-assembled threaded pins (0904.22) in the shaft protection sleeve (0524.01).

Grease the seat of the component that borders on the back plate (0161.00) with Klüber paste UH1 96-402.

Connect the back plate (0161.00) to the structural part,

Use the stud bolts (0902.02), the washers (0554.81) and the hexagon nuts (0920.04). Torque: M12 - 80 Nm

 \rightarrow The single-flushed mechanical seal is installed.

i Hint!

Further installation steps

• The next steps for installing the product-side mechanical seal are identical to installing the single mechanical seal. Therefore, observe the steps in the section "Installing single mechanical seal".

10.4.14 Installing the double mechanical seal tandem

Equipment and tools from the GEA Hilge assembly tool kit

- · Spray bottle
- Plastic mounting sleeve
- Mounting sleeve
- Loctite Type 243
- Klüber paste UH1 96-402
- Extractor
- Socket wrench with plastic insert




Fig.26: Double mechanical seal tandem

| 0161.00 - Housing cover | 0491.00 - Seal cartridge |
|---|----------------------------|
| 0211.00 - Pump shaft | 0507.00 - Deflector |
| 0412.01 - O-ring seal | 0516.00 - Adjusting ring |
| 0412.02 - O-ring seal | 0560.07 - Cylindrical pin |
| 0412.03 - O-ring seal | 1/0904.02" - Threaded pin |
| 0471.00 - Seal cover | 0914.02 - Hex socket screw |
| 0433.00 - Mechanical seal (product side) | 0918.00 - Sterile screw |
| 0433.01 - Mechanical seal (atmosphere side) | |
| | |

Installing the double mechanical seal tandem

Wet the threads of the stud bolts (0902.00) with Loctite Type 243 and screw them by hand (!) into the back plate (0161.00).

Insert the O-ring (0412.02) into the seal cartridge (0491.00).

| | Installing the double mechanical seal tandem |
|---|--|
| | Press the seal cartridge (0491.00) into the seat of back plate (0161.00). |
| | Connect the seal cartridge (0491.00) with the housing cover (0161.00) torque: M6: 8 Nm |
| | Grease the seat of the component that borders on the back plate (0161.00) with Klüber paste UH1 96-402. |
| | Connect the back plate (0161.00) to the structural part, Use the stud bolt (0902.02), the washers (0554.81) and the nuts (0920.04). Torque: M12 - 80 Nm |
| | Wet the fixed ring (stationary ring) of the mechanical seal (0433.01) and the shaft (0211.00) with clean water. |
| | Push the fixed ring (stationary ring) of the mechanical seal (0433.01) with the mounting sleeve into the seat of the seal cartridge (0491.00). |
| | Wet the mounting sleeve with clean water and push it onto the shaft shoulder. |
| | Push the rotating unit (rotary ring) of the mechanical seal (0433.01) into the shaft (0211.00) as far as it will go in the assembled state with the mounting sleeve. |
| | Remove the mounting sleeve. |
| - | Screw threaded pins (0904.02) one or two turns into the adjusting ring (0516.00) and wet with Loctite type 243. |
| | Push the adjusting ring (0516.00) to the correct position on the shaft, using a suitable measuring tool. |
| | Lock the adjusting ring (0516.00) with the threaded pins (0904.02). Adjustment dimensions: HYGIA H III: L=58.9 |
| | Relieve the spring of the mechanical seal (0433.01) against the adjusting ring (0516.00), using the extractor. |
| | Wet the O-ring (0412.03) with water and insert it into the sterile screws (0918.00). |

Installing the double mechanical seal tandem

Insert the O-ring (0412.01) into the seal cover (0471.00).

Use the sterile screws (0918.00) to fasten the seal cover (0471.00) to the back plate (0161.00). Torque: M6: 8 Nm Use the socket wrench with plastic insert to tighten the sterile screws.

 \rightarrow The mechanical seal on the atmosphere side has been installed.

(i) Hint!

The next steps for installing the product-side mechanical seal are identical to installing the single mechanical seal. Therefore, observe the steps in the section "Installing single mechanical seal".

10.4.15 Installing the impeller and housing

Equipment and tools from the GEA Hilge assembly tool kit:

- Klüber paste UH1 96-402
- Extractor
- · Spray bottle
- · Socket wrench
- Socket wrench bit

Install impeller

Insert the key (0940.00).

Grease impeller seat and shaft thread with Klüber paste.

Install impeller (0230.00).

Grease the thread of the impeller nut (0922.00) with Klüber paste.



Fig.27: Impeller nut

Grease lock washer (0930.00) with Klüber paste.

i Hint!

Only use original spare part lock washers from Hilge for securing the impeller mounting.




Fig.28: Lock washers

Grease lock washers as shown.

- (0230.00) impeller | (0412.04) O-ring
- (0922.00) Impeller nut
- (A) Fine gearing greased
- (B) Coarse gearing against each other greased





Fig.29: Grease overview



Install impeller To prevent damage, use socket wrench with bit to tighten the impeller nut (0922.00). **Notice** Hygiene risk, food safety Damaged and scratched surfaces can cause contamination. Always tighten impeller nut with socket Fig.34 wrench and insert. Tighten the impeller nut (0922.00). To do so, lock the impeller (0230.00) with the centring key. Torque M20 x 1.5: 100 - 120 Nm (74 - 89 lbf ft)






Fig.35: Impeller nut

 \rightarrow The impeller has been installed.

Installing the HP housing

Hint! (\mathbf{i})

Transport the housing with a lifting device. Use a suitable eye bolt for this purpose.



Fig.36: Eye bolt for lifting device

Apply Loctite Type 243 to the threads of the stud bolts (0902.29) and screw them tight (!) into the housing (0103.00).



Fig.37: Stud bolts in the HP housing

Installing the HP housing

Wet the O-ring (0412.00) with water and insert it into the back plate (0161.00).

Install the annular casing (0103.00).

Secure the housing (0103.00) with the washers (0554.80) and the hexagon nuts (0920.67). Torques: HYGIA H III (M20): 300 Nm

 \rightarrow The HP housing is installed.

11 Decommissioning

11.1 Special personnel qualification

The decommissioning personnel must be suitably qualified for this work. See also Section 2.6, Page 16.

11.2 Safety instructions

<u> Warning!</u>

Pressure shock!

► Always close shut-off devices (gates, valves) slowly.

► A pressure shock is a sudden increase in pressure in the system. This pressure increase may be triggered by quickly shutting off the flow in the pressure pipe, in addition to other causes. If a pressure shock occurs, the max. permissible pump pressure is briefly exceeded by a multitude.

▲ Caution!

Sticking of the pump.

► Clean the pump suitably after decommissioning. (See Chapter 8,

Page 38

11.3 Temporary decommissioning

Perform the following steps:

- 1. Close the pressure side shut-off valve.
- 2. Switch off the pump.
- 3. Close the suction side shut-off valve.
- 4. Switch off the flushing.
- 5. Make sure that the pump is depressurised.
- 6. Depressurise the sealing system.
 - \rightarrow The pump has been temporarily decommissioned.

11.4 Disposal

Discard the pump or parts thereof in an environment-friendly manner: Use the service of public or private disposal companies. If this is not possible, contact the next GEA Hilge company or service centre.

12 Appendix

12.1 Certificate of non-objection

Certificate of non-objection

This section contains a certificate of non-objection. In the event of inspection or repair send the pump including this certificate to HILGE.

Certificate of non-objection

The following pump and its accessories, together with this certificate of non-objection, are herewith contracted out by the undersigned for inspection/repair:

Pump data

- Model:
- No.:
- Delivery date: Reason for inspection / repair contract

The pump (please mark with a cross)

- ____ was not used in liquids hazardous to health
- ____ was used for the following:

Please state the last liquid pumped, if known:

The pump was carefully drained and also cleaned inside and out before it was shipped/made available. (please mark with a cross).

____ No special safety measures are required in the course of further handling.

____ The following safety measures pertaining to flushing liquids, residual liquids, and disposal are required:

We confirm that the information given above is correct and complete and that shipment is in compliance with legal regulations.

| Company (address |): |
|----------------------------|----|
| Telephone: | |
| Fax: | |
| Email: | |
| Name (incl. title) | |
| (please print): | |
| Date: | |
| Company stamp / signature: | |



We live our values.

Excellence • Passion • Integrity • Responsibility • GEA-versity

GEA is a global technology company with multi-billion euro sales operations in more than 50 countries. Founded in 1881 the company is one of the largest providers of innovative equipment and process technology. GEA is listed in the STOXX[®] Europe 600 Index. In addition, the company is included in selected MSCI Global Sustainability Indexes.

GEA Germany

GEA Hilge Niederlassung der GEA Tuchenhagen GmbH Hilgestraße 37–47 55294 Bodenheim, Germany

Tel +49 6135 7016-0 Fax +49 6135 1737 info@gea.com gea.com