OptiBreaker Basic


The SANOVO OptiBreaker Basic series is the right choice for small and medium sized operations to break and separate eggs with a yield and quality equivalent to the largest and most efficient production facilities in the world.

The OptiBreaker Basic series are available in a basic version with a number of options. The OptiBreaker Basic series is ideal for small or medium sized breaking facilities; companies who want to be self-sufficient or grading stations who need to handle the off graded eggs.


OPTIBREAKER BASIC SERIES - BREAKING AND SEPARATION LINES

BREAKER TYPE	Cases / hour in line	Eggs / hour in line	Loader type	Cases / hour off line	Eggs / hour off line
OptiBreaker Basic 2	60	21,600	Manual SL 30	Operator dependent	
OptiBreaker Basic 5	110	39,600	FlexLoader 5-6 JW6	110 110	36,600 39,600
OptiBreaker Basic 6	135	48,600	FlexLoader 5-6 with destacker	135	48,600
			JW6	135	48,600










SAFETY AND SERVICE


All SANOVO products and systems are designed to meet the industry safety standards.

A comprehensive service organisation is always available to assist in the selection of the right maintenance programme or individual spare part.



OptiBreaker Basic 2 - In-feed Roller Table





OptiBreaker Basic 5/6 - Inclined Roller Table - FlexLoader 5/6 with Destacker

