



# TESTING VACUUM AND PRESSURE FILTRATION

BoFilTest – quick and easy determination of filtration properties.








## **BoFiltest in action**

The simple handling of BoFilTest allows a quick test procedure. Due to the quick-release closures on the upper and lower part of the pressure filter cell, a test can be started immediately after filling in the sample suspension. One hand movement is enough to get BoFilTest ready for a test.

With a filtration area of only 20 cm<sup>2</sup> and a filtration pressure of up to 11 bar (a) BoFilTest allows

- a fast, easy and reproducible analysis of filtration data
- the variation of all filtration parameters such as cake height, pressure difference (for cake formation, washing and dehumidifying), amount of wash liquid
- the determination of the relevant filtration parameters and material parameters for both vacuum and pressure filtration such as: cake forming time, air breakthrough time, wash time, demoisturing time, gas flow rate, cake and filter media resistance, etc.
- the determination of the suitable filter medium
- the production of small amounts of material (solid or filtrate)
- the production of analysis samples (solid or filtrate) for further subsequent analysis

Optionally, the measured values can be electronically recorded and evaluated.







YouTube has been restricted due to privacy settings

BoFilTest in action - filling in of test suspension



YouTube has been restricted due to privacy settings

BoFilTest in action – view of filter cake through sight glass



# Construction

The core of the BoFilTest is a double-walled pressure filter cell made of stainless steel, which can be tempered by a liquid circulation if required. It is closed by a quick release lid with hinge and sight glass. The lower part is attached to the body of the pressure filter cell with a bayonet quick release. In this lower part of the filtrate outlet funnel, a perforated plate as support for the filter medium and a removable cakeforming ring are integrated. The pressure filter cell is mounted on a base frame in which a laptop holder is integrated. In the basic version, this device is supplemented by a manometer for setting and measuring the filtration pressure difference.

The basic version was deliberately designed in such a way that it can be operated on site even without power supply. The versatility and ease-of-use of the BoFilTest can be adapted at any time to suit individual requirements by means of various, mostly metrological, auxiliaries.





### BoFilTest - basic version with auxiliaries

# **Technical data**

Feature	Data/Specifications
Filtration Area	20 cm <sup>2</sup>
Volume	380 cm <sup>3</sup>
Filtration pressure p, abs	11 bar
Operation temperature	max. 120 °C
Height of filter cake	50 mm (on demand up to 100 mm)
Dimensions (W $\times$ L $\times$ H)	815 × 680 × 330 mm
Tempering	heated double jacket
Lid	quick-release lid with sight glass for quick test start (one-hand operation)
Bottom	bayonet lock (one-hand operation)
Compressed air connection	quick coupling
Material	SS316 stainless steel for wetted parts, SS304 for non-wetted parts

# **Auxiliaries**

Supplementary equipment can be ordered separately and may be integrated subsequently into the basic version without any mechanical effort. The modular structure includes the following components:

- electronic filtrate measurement with scale
- electronic gas flow meter with a large measuring range (pos. 2 in picture)
   (It is no longer necessary to estimate and preset gas consumption before starting the test)
- interface box for power supply of all components and for bundled data transfer via USB connection (pos. 3 in picture)
- electronic precision measuring gauge
- software for BoFilTest program for fast & safe data evaluation (pos. 4 in picture)
   (compatible with current and older Windows versions up to Windows XP)
- hardware (PC or laptop) for BoFilTest software (pos. 4 in picture)



Tel. +49 721 96456-0 Fax+49 721 96456-10 info@bokela.com bokela.com



- lighting unit for the interior of the filter cell
- transport case
- other equipment/options such as
  - version in special materials
  - filter area reduction
  - cake height measurement device
  - cake washing device

Older versions of the portable filtration test equipment Filtratest can be upgraded to the current BoFilTest design using an upgrade kit consisting of 4 components (see picture):

- 1. base frame made of stainless steel hollow profiles including base plate and laptop holder
- 2. new electronic gas flow measurement device
- 3. interface box
- 4. software for BoFilTest program





